

# P-974H/HW Series

*Cable Router*

## *User's Guide*

### Default Login Details

IP Address	http:// 192.168.1.1:8080
User Name	webadmin
Password	1234

Firmware Version 3.70  
Edition 2, 09/2009

[www.zyxel.com](http://www.zyxel.com)

# **ZyXEL**



# About This User's Guide

## Intended Audience

This manual is intended for people who want to configure the ZyXEL Device using the web configurator. You should have at least a basic knowledge of TCP/IP networking concepts and topology.

## Related Documentation

- Quick Start Guide

The Quick Start Guide is designed to help you get up and running right away. It contains information on setting up your network and configuring for Internet access.

- Support Disc

Refer to the included CD for support documents.

- ZyXEL Web Site

Please refer to [www.zyxel.com](http://www.zyxel.com) for additional support documentation and product certifications.

## User Guide Feedback

Help us help you. Send all User Guide-related comments, questions or suggestions for improvement to the following address, or use e-mail instead. Thank you!

The Technical Writing Team,  
ZyXEL Communications Corp.,  
6 Innovation Road II,  
Science-Based Industrial Park,  
Hsinchu, 300, Taiwan.

E-mail: [techwriters@zyxel.com.tw](mailto:techwriters@zyxel.com.tw)

# Document Conventions

## Warnings and Notes

These are how warnings and notes are shown in this User's Guide.

**Warnings tell you about things that could harm you or your device.**










Note: Notes tell you other important information (for example, other things you may need to configure or helpful tips) or recommendations.

## Syntax Conventions

- This product may be referred to as the "ZyXEL Device", the "device" or the "system" in this User's Guide.
- Product labels, screen names, field labels and field choices are all in **bold** font.
- A key stroke is denoted by square brackets and uppercase text, for example, [ENTER] means the "enter" or "return" key on your keyboard.
- "Enter" means for you to type one or more characters and then press the [ENTER] key. "Select" or "choose" means for you to use one of the predefined choices.
- A right angle bracket ( > ) within a screen name denotes a mouse click. For example, **Maintenance > Log > Log Setting** means you first click **Maintenance** in the navigation panel, then the **Log** sub menu and finally the **Log Setting** tab to get to that screen.
- Units of measurement may denote the "metric" value or the "scientific" value. For example, "k" for kilo may denote "1000" or "1024", "M" for mega may denote "1000000" or "1048576" and so on.
- "e.g.," is a shorthand for "for instance", and "i.e.," means "that is" or "in other words".

## Icons Used in Figures

Figures in this User's Guide may use the following generic icons. The ZyXEL Device icon is not an exact representation of your device.

ZyXEL Device 	Computer 	Notebook computer 
Server 	Printer 	Firewall 
Telephone 	Switch 	Router 

# Safety Warnings

- Use only No. 26 AWG (American Wire Gauge) or larger telecommunication line cord.
- Do NOT use this product near water, for example, in a wet basement or near a swimming pool.
- Do NOT expose your device to dampness, dust or corrosive liquids.
- Do NOT store things on the device.
- Do NOT install, use, or service this device during a thunderstorm. There is a remote risk of electric shock from lightning.
- Connect ONLY suitable accessories to the device.
- Do NOT open the device or unit. Opening or removing covers can expose you to dangerous high voltage points or other risks. ONLY qualified service personnel should service or disassemble this device. Please contact your vendor for further information.
- Make sure to connect the cables to the correct ports.
- Place connecting cables carefully so that no one will step on them or stumble over them.
- Always disconnect all cables from this device before servicing or disassembling.
- Use ONLY an appropriate power adaptor or cord for your device.
- Connect the power adaptor or cord to the right supply voltage (for example, 110V AC in North America or 230V AC in Europe).
- Do NOT allow anything to rest on the power adaptor or cord and do NOT place the product where anyone can walk on the power adaptor or cord.
- Do NOT use the device if the power adaptor or cord is damaged as it might cause electrocution.
- If the power adaptor or cord is damaged, remove it from the power outlet.
- Do NOT attempt to repair the power adaptor or cord. Contact your local vendor to order a new one.
- Do not use the device outside, and make sure all the connections are indoors. There is a remote risk of electric shock from lightning.
- Do NOT obstruct the device ventilation slots, as insufficient airflow may harm your device.
- Antenna Warning! This device meets FCC certification requirements when using the included antenna(s). Only use the included antenna(s).
- Make sure that the cable system is grounded so as to provide some protection against voltage surges.

This product is recyclable. Dispose of it properly.







# Table of Contents

<b>About This User's Guide .....</b>	<b>3</b>
<b>Document Conventions.....</b>	<b>4</b>
<b>Safety Warnings.....</b>	<b>6</b>
<b>Table of Contents.....</b>	<b>9</b>
<b>List of Figures .....</b>	<b>13</b>
<b>List of Tables.....</b>	<b>15</b>
<b>Part I: Introduction and Configuration .....</b>	<b>17</b>
<b>Chapter 1</b>	
<b>Introduction .....</b>	<b>19</b>
1.1 Overview .....	19
1.2 Internet Access Application .....	19
1.3 Hardware Connection and Installation .....	20
1.4 Front Panel LED Description .....	20
<b>Chapter 2</b>	
<b>The Web Configurator .....</b>	<b>23</b>
2.1 Overview .....	23
2.2 Accessing the Web Configurator .....	23
2.2.1 Logging Out of the Web Configurator .....	24
2.2.2 Resetting the ZyXEL Device .....	24
2.3 Navigating the Web Configurator .....	25
2.4 Changing the Login Password .....	26
<b>Chapter 3</b>	
<b>Status .....</b>	<b>29</b>
3.1 Overview .....	29
3.1.1 What You Can Do in This Chapter .....	29
3.1.2 What You Need to Know .....	29
3.2 Software .....	31
3.3 Connection .....	32
3.4 Event Log .....	37
3.4.1 Event Log: Log Description .....	38

<b>Chapter 4</b>	
<b>Basic .....</b>	<b>43</b>
4.1 Overview .....	43
4.1.1 What You Can Do in This Chapter .....	43
4.1.2 What You Need to Know .....	43
4.2 DHCP .....	44
<b>Chapter 5</b>	
<b>Advanced.....</b>	<b>45</b>
5.1 Overview .....	45
5.1.1 What You Can Do in this Chapter .....	45
5.1.2 What You Need to Know .....	45
5.2 Options .....	46
5.3 IP Filtering .....	47
5.4 MAC Filtering .....	48
5.5 Port Filtering .....	49
5.6 Port Forwarding .....	50
<b>Chapter 6</b>	
<b>Wireless LAN.....</b>	<b>51</b>
6.1 Overview .....	51
6.1.1 What You Need to Know .....	52
6.2 Basic WLAN Settings .....	54
6.3 Wireless LAN Security .....	55
6.3.1 WEP Encryption .....	55
6.3.2 Introduction to WPA(2) .....	57
6.3.3 WPA/WPA2 .....	58
6.3.4 WPA-PSK/WPA2-PSK .....	60
6.4 Access Control .....	61
<b>Chapter 7</b>	
<b>Maintenance .....</b>	<b>63</b>
7.1 Overview .....	63
7.1.1 What You Can Do in this Chapter .....	63
7.2 Security .....	63
7.3 Diagnostics .....	64
7.4 Band .....	66
<b>Part II: Appendices and Index.....</b>	<b>69</b>
Appendix A Product Specifications.....	71

Appendix B Sample Configurations.....	77
7.5 Overview .....	77
7.6 Connecting to the ZyXEL Device with Telnet .....	77
7.6.1 Set Static IP Only .....	78
7.6.2 Set Static IP with Public DHCP .....	78
7.6.3 Set Static IP with NAT .....	79
7.6.4 Set Static IP with NAT and Private DHCP .....	79
7.6.5 Set Bridge Mode .....	80
7.6.6 Set Default IP Sharing / RG Mode .....	80
Appendix C Setting up Your Computer's IP Address .....	81
Appendix D Common Services .....	99
Appendix E Legal Information .....	103
Appendix F Customer Support .....	107
<b>Index.....</b>	<b>113</b>



# List of Figures

Figure 1 Internet Access Application .....	19
Figure 2 Front Panel LEDs: P-974H .....	20
Figure 3 Front Panel LEDs: P-974HW .....	20
Figure 4 Status .....	25
Figure 5 Maintenance: Security .....	26
Figure 6 Status: SOFTWARE .....	31
Figure 7 Status: CONNECTION .....	32
Figure 8 Status: EVENT LOG .....	37
Figure 9 Basic: DHCP .....	44
Figure 10 Advanced: Options .....	46
Figure 11 Advanced: IP Filtering .....	47
Figure 12 Advanced: MAC Filtering .....	48
Figure 13 Advanced: Port Filtering .....	49
Figure 14 Advanced: Forwarding .....	50
Figure 15 Example of a Wireless Network .....	51
Figure 16 Wireless: Basic .....	54
Figure 17 Wireless: Security: WEP .....	56
Figure 18 Wireless: Security: WPA .....	58
Figure 19 Wireless: Security: WPA-PSK .....	60
Figure 20 Wireless: Access Control .....	61
Figure 21 Maintenance: Security .....	63
Figure 22 Maintenance: Diagnostic (Ping) .....	64
Figure 23 Maintenance: Diagnostic (Traceroute) .....	65
Figure 24 Maintenance: Band .....	66
Figure 25 WIndows 95/98/Me: Network: Configuration .....	82
Figure 26 Windows 95/98/Me: TCP/IP Properties: IP Address .....	83
Figure 27 Windows 95/98/Me: TCP/IP Properties: DNS Configuration .....	84
Figure 28 Windows XP: Start Menu .....	85
Figure 29 Windows XP: Control Panel .....	85
Figure 30 Windows XP: Control Panel: Network Connections: Properties .....	86
Figure 31 Windows XP: Local Area Connection Properties .....	86
Figure 32 Windows XP: Internet Protocol (TCP/IP) Properties .....	87
Figure 33 Windows XP: Advanced TCP/IP Properties .....	88
Figure 34 Windows XP: Internet Protocol (TCP/IP) Properties .....	89
Figure 35 Macintosh OS 8/9: Apple Menu .....	90
Figure 36 Macintosh OS 8/9: TCP/IP .....	91
Figure 37 Macintosh OS X: Apple Menu .....	92
Figure 38 Macintosh OS X: Network .....	92

Figure 39 Red Hat 9.0: KDE: Network Configuration: Devices .....	93
Figure 40 Red Hat 9.0: KDE: Ethernet Device: General .....	94
Figure 41 Red Hat 9.0: KDE: Network Configuration: DNS .....	94
Figure 42 Red Hat 9.0: KDE: Network Configuration: Activate .....	95
Figure 43 Red Hat 9.0: Dynamic IP Address Setting in ifconfig-eth0 .....	95
Figure 44 Red Hat 9.0: Static IP Address Setting in ifconfig-eth0 .....	96
Figure 45 Red Hat 9.0: DNS Settings in resolv.conf .....	96
Figure 46 Red Hat 9.0: Restart Ethernet Card .....	96
Figure 47 Red Hat 9.0: Checking TCP/IP Properties .....	97

# List of Tables

Table 1 Front Panel LEDs .....	20
Table 2 Web Configurator Screens Summary .....	25
Table 3 Maintenance: Security .....	27
Table 4 Status: SOFTWARE .....	31
Table 5 Status: CONNECTION .....	33
Table 6 Status: CONNECTION: Startup Procedure .....	35
Table 7 Status: EVENT LOG .....	37
Table 8 Event Log: Severity Levels .....	37
Table 9 Event Log: Log Description .....	38
Table 10 Basic: DHCP .....	44
Table 11 Advanced: Options .....	46
Table 12 Advanced: IP Filtering .....	47
Table 13 Advanced: MAC Filtering .....	48
Table 14 Advanced: Port Filtering .....	49
Table 15 Advanced: Forwarding .....	50
Table 16 Types of Encryption for Each Type of Authentication .....	53
Table 17 Wireless: Basic .....	54
Table 18 Wireless: Security: WEP Encryption .....	56
Table 19 Wireless: Security: WPA/WPA2 .....	59
Table 20 Wireless: Security: WPA-PSK .....	60
Table 21 Wireless: Access Control .....	62
Table 22 Maintenance: Security .....	64
Table 23 Maintenance: Diagnostics (Ping) .....	65
Table 24 Maintenance: Diagnostics (Traceroute) .....	66
Table 25 Maintenance: Band .....	67
Table 26 Firmware Features .....	71
Table 27 IEEE802.11b/g .....	72
Table 28 Device Specifications .....	72
Table 29 P-974H/HW Power Adaptor Specifications .....	74
Table 30 Commonly Used Services .....	99





---

# PART I

## Introduction and Configuration

---

Introduction	(19)
The Web Configurator	(23)
Status	(29)
Basic	(43)
Advanced	(45)
Wireless LAN	(51)
Maintenance	(63)



# Introduction

## 1.1 Overview

This user's guide explains how to configure the following ZyXEL devices:

- The P-974H model is a 4-port cable modem and router combined. It also has a USB 2.0 port allowing computers without an Ethernet connection to join your network.
- The P-974HW model adds IEEE 802.11g wireless capability allowing wireless clients to join your network.

This user's guide refers to these models simply as the "ZyXEL Device". Please refer to [Appendix A on page 71](#) for a complete list of features for your model.

## 1.2 Internet Access Application

The ZyXEL Device is the ideal high-speed Internet access solution. It is compliant with the DOCSIS 2.0 and Cable Home 1.1 standards. The ZyXEL Device allows you to connect up to four computers to its 10/100 Mbps Ethernet ports and an additional computer to its USB 2.0 port to form your local area network and connect to the Internet. In addition, for P-974HW, wireless clients can access your network resources and the Internet.

**Figure 1** Internet Access Application



## 1.3 Hardware Connection and Installation

Refer to the Quick Start Guide for information for hardware connections and USB driver installation.

## 1.4 Front Panel LED Description

The following figures are front panel images of the P-974HW and P-974H models respectively. The LED behavior is described at the end of this section.

**Figure 2** Front Panel LEDs: P-974H



**Figure 3** Front Panel LEDs: P-974HW



The following table describes the LEDs.

**Table 1** Front Panel LEDs

LED	COLOR	STATUS	DESCRIPTION
PWR	Green	On	The ZyXEL Device is receiving power.
		Off	The ZyXEL Device is not receiving power.
SYS	Green	On	The ZyXEL Device is functioning properly.
		Off	The system is not ready or has malfunctioned.

**Table 1** Front Panel LEDs (continued)

LED	COLOR	STATUS	DESCRIPTION
LAN 1...4	Green	On	The ZyXEL Device has a successful 10/100Mb Ethernet connection.
		Blinking	The ZyXEL Device is sending/receiving data.
		Off	The LAN is not connected.
USB	Green	On	A device is connected to the USB port on the ZyXEL Device.
		Blinking	The ZyXEL Device is sending/receiving data via the USB port.
		Off	The USB port is not connected.
WLAN	Green	On	The wireless LAN is enabled.
		Blinking	The ZyXEL Device is sending/receiving data through the wireless LAN.
		Off	The wireless LAN is disabled.
DATA	Green	Blinking	The ZyXEL Device is sending/receiving data on the WAN.
		Off	The ZyXEL Device is not sending/receiving data on the WAN.
CABLE	Green	On	The ZyXEL Device has successfully registered to the cable operator's network.
		Blinking	The ZyXEL Device is trying to register with the cable operator's network.
		Off	The coaxial cable is not connected or the cable link is down.



# The Web Configurator

## 2.1 Overview

The web configurator is an HTML-based management interface that allows easy setup and management via an Internet browser. Use Internet Explorer 6.0 and later or Firefox 1.5 and later versions. The recommended screen resolution is 1024 by 768 pixels.

In order to use the web configurator you need to allow:


- Web browser pop-up windows from your device. Web pop-up blocking is enabled by default in Windows XP SP (Service Pack) 2.
- JavaScript (enabled by default).
- Java permissions (enabled by default).

See the chapter on troubleshooting to see how to make sure these functions are allowed in Internet Explorer or Firefox.

## 2.2 Accessing the Web Configurator

Follow the steps below to log into the web configurator.

- 1 Launch your web browser. Enter "192.168.1.1:8080" as the web site address.



- 2 Enter the user name ("user" is the default) password ("1234" is the default) or enter the administrator user name ("webadmin" is the default) and password ("1234" is the default) and click **OK**.



- 3 You should now see the main **Status** screen (refer to [Figure 4 on page 25](#)).

## 2.2.1 Logging Out of the Web Configurator

To log out of the Web Configurator - perhaps to log in under a different account - you must close the web browser in which it is displayed and then clear your browser cache. If you do not, then the next time you re-open the web page in that browser you may not have been properly logged out.

For instructions on how to empty your web browser cache, see the documentation that shipped with it.

## 2.2.2 Resetting the ZyXEL Device

If you forget your password or cannot access the web configurator, you will need to use the **RESET** button at the back of the ZyXEL Device to reload the factory-default configuration file. This means that you will lose all configurations that you had previously and the password will be reset to "1234".

### 2.2.2.1 Using the RESET Button

- 1 Make sure the **PWR** and **SYS** LEDs are on (not blinking).
- 2 Press and hold the **RESET** button for about 15 seconds. All LEDs (except the **WLAN** LED on the P-974HW) should turn on. When you release the **RESET** button, the defaults have been restored and the ZyXEL Device restarts.




You can also use the **RESET** button to restart the ZyXEL Device (without restoring the defaults) by pressing down for 2 to 14 seconds.

## 2.3 Navigating the Web Configurator

The following summarizes how to navigate the web configurator from the main **Status** screen.

**Figure 4** Status



Following table lists the menu screens.

**Table 2** Web Configurator Screens Summary

LINK	SUB-LINK	FUNCTION
Status	Software	Use this screen to view firmware and system related information.
	Connection	Use this screen to view LAN/WAN/WLAN connection information.
	Event Log	Use this screen to view system logs.
Basic	DHCP	Use this screen to configure DHCP settings on the LAN.

**Table 2** Web Configurator Screens Summary (continued)

LINK	SUB-LINK	FUNCTION
Advanced	Options	Use this screen to activate/deactivate WAN features (such as IPSec passthrough and Multicast).
	IP Filtering	Use this screen to block access from one or a range of IP addresses.
	MAC Filtering	Use this screen to block access from the specified MAC address(es).
	Port Filtering	Use this screen to block access from one or a range of ports.
	Forwarding	Use this screen to configure port forwarding on your network.
Wireless (P-974HW Only)	Basic	Use this screen to configure the wireless LAN settings.
	Security	Use this screen to configure WLAN authentication and security settings.
	Access Control	Use this screen to configure MAC filter settings on the ZyXEL Device.
	Bridging	Use this screen to configure WLAN bridging.
Maintenance	Security	Use this screen to change system password or reset the ZyXEL Device back to the factory defaults.
	Diagnostics	These screens display information to help you identify problems with the ZyXEL Device general connection.
	Band	Use this screen to set up scan sets for Internet access providers.

## 2.4 Changing the Login Password

It is highly recommended that you periodically change the password for accessing the ZyXEL Device. If you didn't change the default one after you logged in or you want to change to a new password again, then click **Maintenance** > **Security** to display the screen as shown next.

**Figure 5** Maintenance: Security

The screenshot shows the 'Security' configuration page in the ZyXEL Web Configurator. The page has a header with three tabs: 'Security' (selected), 'Diagnostics', and 'Band'. Below the tabs, the title 'Security' is displayed. The main content area contains four input fields: 'Password Change User ID', 'New Password', 'Re-Enter New Password', and 'Current User ID Password'. These fields are enclosed in a red rectangular box. Below the input fields, there is a 'Restore Factory Defaults' label followed by two radio buttons: 'Yes' and 'No'. The 'No' radio button is selected. At the bottom right of the page, there is an 'Apply' button.

The following table describes the related labels in this screen.

**Table 3** Maintenance: Security

LABEL	DESCRIPTION
Password Change User ID	Enter the login user name whose password you want to change. The default user name is "user".
New Password	Type the new password in this field.  Passwords may be up to 16 characters in length and must be alphanumeric (a-z, A-Z, 0-9), no other characters are allowed.
Re-enter New Password	Type the new password again in this field.
Current User ID Password	Type the default password or the existing password (associated with the user name you enter above) you use to access the system in this field. The default password is "1234".
Apply	Click <b>Apply</b> to save your changes.



## 3.1 Overview

This chapter describes the Status screens you can display to view firmware and system information and system logs.

### 3.1.1 What You Can Do in This Chapter

- The **Software** screen allows you to view the overall status of your device ([Section 3.2 on page 31](#)).
- The **Connection** screen displays all of your network connection details ([Section 3.3 on page 32](#)).
- The **Event Log** screen provides a composite list of all system even records ([Section 3.4 on page 37](#)).

### 3.1.2 What You Need to Know

The following terms and concepts may help as you read through this chapter.

#### Acquire Downstream Channel

In order to establish a successful connection with the cable provider's network, the ZyXEL Device must first find and lock onto a frequency for communication with the cable operator's network. The frequency is called a channel. Communication with the cable operator's network cannot proceed until the ZyXEL Device finds the specific channel for sending and receiving data.

#### Connectivity State

The connectivity state is the current status of the connection between the cable modem and your cable operator. During the initial negotiation with your cable operator's CMTS (Cable Modem Termination System), the ZyXEL Device must establish a clear upstream and downstream channel, which it accomplishes in a series of well defined steps.

To provide Internet access services, a cable provider's CMTS gets the incoming traffic from the ZyXEL Device and routes the traffic to an ISP (Internet Service Provider) to the Internet.

## Boot State

When downloading the configuration file and booting, your ZyXEL Device passes through several negotiation stages with the cable operator's CMTS. All communication steps: TFTP, DHCP Offer/Response, and Time Server must complete in order for the configuration to be successful. TFTP is the download protocol used to install the configuration file.

If there is a problem making a TFTP connection with the cable operator's CMTS, you will see the message **Waiting for TFTP**. If the ZyXEL Device does not receive a DHCP offer from the cable operator's CMTS you will see the message **Waiting for DHCP Offer**. Once the ZyXEL Device has responded to the DHCP offer it again waits for a response from the CMTS, if it does not receive a response you will see the message **Waiting for DHCP Response**. If the cable operator's time server does not respond you will see the message **Waiting for Timer Server**. If the download and installation of the configuration file succeeds you will see the message **Operational**.

Your cable modem must receive an offer of a DHCP IP Address from the cable operator's CMTS and respond to that offer in order to set your IP Address. First your cable modem is **Waiting for DHCP Offer**, if the offer is received by your cable modem it responds **Waiting for DHCP Response** to the cable operator's CMTS. Once a response is received your IP Address is set and can be viewed under the **CM IP Address** section of the **Connection** screen or in the **Software** status screen. Note that the DHCP IP Address setting must be completed successfully in order for your cable modem to download the configuration file.

## Configuration File

This is the name of the cable modem configuration file downloaded from the cable operator's CMTS using the TFTP protocol. This is a binary format file which must be DOCSIS 2.0 compliant (see RFC 2132 for additional information).

## Security

Your cable modem has features built-in to run Baseline Privacy (BP). BP is used as a privacy mechanism to protect user data flowing across the cable network and to prevent unauthorized access to the cable operator's CMTS data flowing across the network. BP also supports access control lists (ACLs), filtering, tunnels, spoof protection, and source IP filtering on the RF subnets to prevent users from using IP addresses that are invalid. BP security information must be included in your cable operator's configuration file to enable security. If your cable operator did not

supply this information in the configuration file BP security is **Disabled**. Further information can be found in DOCSIS 2.0.

## Channels

Your ZyXEL Device uses different communications methods if it is receiving information from the cable operator, or if it is sending information to the cable operator. These are called the **Downstream Channel** and **Upstream Channel** respectively. The channel numbers and frequencies are advertised by the cable operator's CMTS during the initial booting of the ZyXEL Device; these may also be set in the configuration file.

## 3.2 Software

Click **Status > SOFTWARE** to display the following screen. These fields are read-only and strictly for diagnostic purposes.

**Figure 6** Status: SOFTWARE



The following table describes the labels in this screen.

**Table 4** Status: SOFTWARE

LABEL	DESCRIPTION
Software Information	
Standard Specification Compliant	This field displays the name and version of the standard to which the ZyXEL Device is compliant.
Hardware Version	This field displays the hardware version number.
Software Version	This is the firmware version.
Cable Modem MAC Address	This is the MAC (Media Access Control) or Ethernet address unique to your ZyXEL Device.
Cable Modem Serial Number	This is the serial number unique to your device.

**Table 4** Status: SOFTWARE (continued)

LABEL	DESCRIPTION
CM certificate	Authentication certificates are required for the ZyXEL Device to establish a connection to the cable service provider's network. This field displays whether the authentication certificates are installed on the ZyXEL Device.
Software Status	
System Up Time	This is the elapsed time the system has been up.
Network Access	This field displays whether the ZyXEL Device is registered to the cable service provider's network.
Cable Modem IP Address	This field displays the WAN IP address.

## 3.3 Connection

Click **Status > CONNECTION** to display the read-only screen.

**Figure 7** Status: CONNECTION

The screenshot displays the 'Status: CONNECTION' interface with the following sections:

- Startup Procedure** (Table):
 

Procedure	Status	Comment
Acquire Downstream Channel	681000000 Hz	In Progress
Connectivity State	In Progress	Not Synchronized
Boot State	In Progress	Unknown
Configuration File	In Progress	
Security	Disabled	Disabled
- Downstream Channel** (List):
  - Lock Status: Not Locked
  - Modulation: unknown
  - Channel ID: 0
  - Symbol rate: Unknown
  - Downstream Frequency: 681000000 Hz
  - Downstream Power: -25.6 dBmV
  - SNR: 0.0 dB
- Upstream Channel** (List):
  - Lock Status: Not Locked
  - Modulation: QPSK
  - Channel ID: 0
  - Symbol rate: 0 Ksym/sec
  - Upstream Frequency: 0 Hz
  - Upstream Power: 8.3 dBmV
- Current System Time** (List):
  - CM IP Address: ---:---:---
  - Duration: D: -- H: -- M: -- S: --
  - Expires: ---:---:---
  - Current System Time: ---:---:---



The following table describes the labels in this screen.

**Table 5** Status: CONNECTION

LABEL	DESCRIPTION
Startup Procedure	To establish a successful connection to the cable provider's network, the ZyXEL Device must go through a series of well-defined initialization steps.  This table shows the line initialization information. For detailed information for each initialization step, refer to <a href="#">Table 6 on page 35</a> .
Procedure	This field displays the name of the initialization step.
Status	This field displays the status of the initialization step.
Comment	This field displays the status message of the initialization step.
Downstream/Upstream Channel	This is the data path used by the cable operator's CMTS for sending/receiving information to/from your ZyXEL Device.
Lock Status	The ZyXEL Device is either <b>Locked</b> or <b>Not Locked</b> on to the channel advertised by the cable operator's CMTS.
Modulation	This is the method used to encode transmission information, similar to FM or AM on your radio.  The ZyXEL Device supports <b>QAM64</b> (Quadrature Amplitude Modulation) or <b>QAM256</b> for the downstream channel.  The ZyXEL Device supports <b>QAM16</b> or <b>QPSK</b> (Quadrature Phase Shift Keying) for the upstream channel.
Channel ID	A standard channel number from the DOCSIS 2.0 specification. Channel numbers and channel frequencies are specified in pairs in DOCSIS 2.0.
Symbol Rate	The symbol rate (in Kilo symbols/second) for communication between the cable operator's CMTS and the ZyXEL Device. This is set during initial configuration with a value supplied by the CMTS. Typical values for QAM64 are 5.05 Mega-symbols/second, and for QAM256 5.36 Mega-symbols/second.
Downstream/Upstream Frequency	A standard channel frequency (in hertz) from the DOCSIS 2.0 specification.
Downstream/Upstream Power	The power level (in decibels/mili-volt). This value is set by the cable operator's CMTS.
SNR	This field is applicable for <b>Downstream Channel</b> .  The SNR (Signal to Noise Ratio), in decibels/mili-volt, is the ratio of signal power to channel noise power. This value is set by the cable operator's CMTS.
Current System Time	
CM IP Address	This is the IP address negotiated with your cable operator, after a successful download of the modem configuration file and DHCP negotiation (e.g.10.21.0.11). This field may also be blanked out with a series of dashed lines (--- --- --- ---) indicating that the modem configuration failed or is in progress; no IP address has been set.

**Table 5** Status: CONNECTION (continued)

LABEL	DESCRIPTION
Duration	The IP address negotiated with your cable operator has a default lifetime of 7 days (e.g. D: 00 H: 01 M: 00 S: 00). The sequence ( <b>D -- H -- M -- S --</b> ) indicates that your modem configuration has failed or is in progress; no IP address duration has been set.
Expires	This is the expiration date of the IP address, after installation of the modem configuration file and DHCP negotiation. The default is 7 days (e.g. Wed Jul 02 00:26:23 2005). A sequence of dashes ( <b>--- --- - - - - -- ----</b> ) indicates that your modem configuration has failed or is in progress; no IP address expiry date has been set.
Current System Time	This is the current date and time, and is set by your cable operator's time server.

### 3.3.0.1 Detailed Startup Procedure Information

The following table describes the status for each initialization step in the **CONNECTION** screen.

**Table 6** Status: CONNECTION: Startup Procedure

PROCEDURE	STATUS	COMMENT
Acquire Downstream Channel	The status message will display the frequency in hertz (Hz) of the channel the ZyXEL Device has locked onto or is trying to lock onto.	This field displays: <ul style="list-style-type: none"> <li>• <b>Locked</b> - The ZyXEL Device has locked onto the downstream channel.</li> <li>• <b>In Progress</b> - The ZyXEL Device is trying to find a downstream channel.</li> </ul>
Connectivity State	This field displays: <ul style="list-style-type: none"> <li>• <b>OK</b> - The ZyXEL Device's cable connection is up and the upstream and downstream channels are established.</li> <li>• <b>In Progress</b> - The ZyXEL Device is trying to find and lock onto an upstream channel.</li> </ul>	This field displays: <ul style="list-style-type: none"> <li>• <b>Not Synchronized</b> - The ZyXEL Device can not synchronize the OAM signal timing/FEC framing/MPEG packets or obtain downstream channel MAC address.</li> <li>• <b>Upstream Parameters Acquired</b> - The ZyXEL Device is trying to obtain the upstream channel information from your cable provider network.</li> <li>• <b>Ranging Complete</b> - The ZyXEL Device has successfully adjusted local channel parameters (such as downstream power/frequency and channel ID) within specified ranges.</li> <li>• <b>IP Complete</b> - The ZyXEL Device has successfully obtained a WAN IP address from a DHCP server.</li> <li>• <b>TOD Established</b> - (Time Of Day) The ZyXEL Device has obtained the system time from a time server.</li> <li>• <b>Security Established</b> - The baseline privacy was requested in the configuration file and initialized by the ZyXEL Device.</li> <li>• <b>Params Transfer Complete</b> - The ZyXEL Device has received all initialization parameters.</li> <li>• <b>Registration Complete</b> - The ZyXEL Device has successfully registered to the cable provider network for Internet access.</li> <li>• <b>Operational</b> - The ZyXEL Device has successfully completed all the initialization steps and is working fine.</li> <li>• <b>Access Denied</b> - The ZyXEL Device was unable to perform one or more of the initialization steps.</li> </ul>

**Table 6** Status: CONNECTION: Startup Procedure (continued)


PROCEDURE	STATUS	COMMENT
Boot State	<p>This field displays:</p> <ul style="list-style-type: none"> <li>• <b>In Progress</b> - The ZyXEL Device is in the negotiation process with the cable operator's CMTS.</li> <li>• <b>OK</b> - The ZyXEL Device completed configuration.</li> </ul>	<p>This field displays:</p> <ul style="list-style-type: none"> <li>• <b>Disabled</b> - The ZyXEL Device's WAN connection has been disabled.</li> <li>• <b>Waiting for DHCP Offer</b> - The ZyXEL Device is waiting for a DHCP server to offer it an IP address.</li> <li>• <b>Waiting for DHCP Response</b> - The ZyXEL Device is waiting for a response from the DHCP server.</li> <li>• <b>Waiting for Time Server</b> - The ZyXEL Device is waiting for a response from the time server.</li> <li>• <b>Waiting for TFTP</b> - The ZyXEL Device is waiting for a response from the TFTP server.</li> <li>• <b>Operational</b> - The ZyXEL Device has successfully gone through the boot up process.</li> <li>• <b>Refused by CMTS</b> - The ZyXEL Device could not complete one of the initialization steps.</li> </ul>
Configuration File	<p>This field displays:</p> <ul style="list-style-type: none"> <li>• <b>OK</b> - The ZyXEL Device obtains a configuration file (cmb.cfg) from the cable operator's CMTS, and installs it.</li> <li>• <b>In Progress</b> - The ZyXEL Device is trying to obtain a configuration file from the cable operator's CMTS.</li> </ul>	<p>This field displays:</p> <ul style="list-style-type: none"> <li>• The name of the configuration file on the ZyXEL Device.</li> <li>• Nothing if there was a problem in obtaining or installing the configuration file.</li> </ul>
Security	<p>This field displays:</p> <ul style="list-style-type: none"> <li>• <b>Enabled</b> - The baseline privacy security is activated on the ZyXEL Device.</li> <li>• <b>Disabled</b> - The baseline privacy security is disabled on the ZyXEL Device.</li> </ul>	<p>This field displays:</p> <ul style="list-style-type: none"> <li>• <b>BPI +</b> - Baseline Privacy Interface is activated.</li> <li>• <b>Disabled</b> - Baseline Privacy is disabled.</li> </ul>

## 3.4 Event Log

The **Event Log** screen displays system logs. The logs are useful for debugging purposes when attempting to troubleshoot a connection problem between your ZyXEL Device and the cable operator's CMTS.

Click **Status > EVENT LOG** to display the screen as shown.

**Figure 8** Status: EVENT LOG



Time	Priority	Description
Time Not Established	Critical (3)	Resetting the cable modem due to console command
Time Not Established	Critical (3)	DHCP WARNING - Non-critical field invalid in response.
Sat Jul 12 20:16:01 2036	Critical (3)	Resetting the cable modem due to console command
Time Not Established	Critical (3)	DHCP WARNING - Non-critical field invalid in response.
Time Not Established	Critical (3)	SYNC Timing Synchronization failure - Failed to acquire QAM/Q...
Time Not Established	Critical (3)	SYNC Timing Synchronization failure - Failed to acquire FEC f...

Clear Log

The following table describes the labels in this screen.

**Table 7** Status: EVENT LOG

LABEL	DESCRIPTION
Time	This field displays the name of the log and the time created.
Priority	This field displays the severity level of the log.
Description	This field displays detailed information about the log.
Clear Log	Click <b>Clear Log</b> to erase the log(s) in this screen.

The following table describes the log severity levels in the **Priority** field.

**Table 8** Event Log: Severity Levels

ERROR	LEVEL	DESCRIPTION
Emergency	1	The event log requires immediate attention. Problems resulting from this event may affect your Internet access connection.
Alert	2	A system or connection failure has occurred.
Critical	3	Action(s) should be taken to avoid a system or connection failure.
Error	4	Action(s) should be taken to avoid possible future system or connection failures.
Warning	5	Failure to solve this warning can lead to further system problems,
Notice	6	Normal status. System administrators take notice.
Informational	7	Informational message only. May or may not be significant.
Debug	8	System debugging is turned on.

### 3.4.1 Event Log: Log Description

The following table describes the logs. Refer to DOCSIS 2.0 for additional information on SNMP status messages for cable modems.

**Table 9** Event Log: Log Description

LOG NAME	SEVERITY	DESCRIPTION
DHCP Warning - Non-critical field invalid in response	Critical	The ZyXEL Device has received a response to its DHCP request from the cable operator's CMTS, but the responding DHCP server did not include all of the required fields in the message. This message might also appear if one of the required fields in the DHCP message contains an invalid value. Reconfigure the DHCP server so that it sends all of the required fields.
DHCP ERROR - The DHCP response does not contain all of the required fields or the PS (Portal Services) is unable to determine provisioning mode.	Critical	The ZyXEL Device has received a response to its DHCP request from the cable operator's CMTS, but the responding DHCP server did not include all of the required fields in the message. Please refer to appendix C of the DOCSIS 1.0 RF specification, appendix D of the DOCSIS 1.1 RF specification, appendix D of the DOCSIS 2.0 RF specification, and RFC 868 for further information. Reconfigure the DHCP server so that it sends all of the required fields.
SYNC Timing Synchronization failure - Failed to acquire FEC framing	Critical	When attempting to lock on to the downstream channel your ZyXEL Device could not acquire forward error correction (FEC) framing.
SYNC Timing Synchronization failure - Failed to acquire MAC framing	Critical	Your ZyXEL Device attempted to lock on to the downstream channel and was able to acquire forward error correction (FEC) framing, but then failed to lock on to media access control (MAC) framing. Note that this is not an ethernet MAC frametype.
SYNC Timing Synchronization failure, Acquired FEC framing - Failed to acquire MPEG2 Sync	Critical	Your ZyXEL Device attempted to lock on to the downstream channel and was able to acquire forward error correction (FEC) framing, but then failed to lock on to the MPEG2 synchronization signal.
SYNC Timing Synchronization failure - Failed to acquire QAM/QPSK symbol timing	Critical	Your ZyXEL Device could not lock on to the downstream channel's quadrature amplitude modulation/quadrature phase shift keying (QAM)/(QPSK) signal.
SYNC Timing Synchronization failure - Failed to receive MAC SYNC frame within time-out period	Critical	Your ZyXEL Device was able to acquire the media access control (MAC) framing initially, but subsequently failed to receive the MAC SYNC frame within the specified timeout period. Note that this is not an ethernet MAC frame type.

**Table 9** Event Log: Log Description (continued)

LOG NAME	SEVERITY	DESCRIPTION
SW Upgrade Failed Before Download - Server not Present	Error	Your ZyXEL Device has made 16 unsuccessful attempts to download a new ZyXEL software image from the TFTP server (CMTS or other TFTP server). After 16 attempts your cable modem aborts the upgrade procedure. This error message might also occur if your cable modem has received a fatal TFTP server error.
SW upgrade Failed after download - Incompatible SW file	Error	An upgrade of your ZyXEL Device software failed because the downloaded image file was either the wrong image, type, or was corrupted during file transfer.
UCD invalid or channel unusable	Critical	The cable modem received an Upstream Channel Descriptor (UCD) message from the CMTS, but it contains invalid information or specifies an upstream channel that is unusable.
A transmit opportunity was missed because the MAP arrived too late	Information	Your ZyXEL Device missed a transmit opportunity because the Bandwidth Allocation MAP (one slot of the Time Division Multiplexing) signal arrived too late for your ZyXEL Device to use it.
DHCP FAILED - Discover sent, no offer received	Critical	Your ZyXEL Device sent a DHCP discovery broadcast message to the cable operator's CMTS, but no DHCP server or DHCP relay agent replied with a DHCP offer response message.
DHCP FAILED - Request sent, No response	Critical	Your ZyXEL Device sent a DHCP discovery broadcast message to the cable operator's CMTS, and received a DHCP offer message in response from the cable operator, but when it sent a DHCP request message to the indicated DHCP server, it did not receive a DHCP response message.
No UCD's Received - Timeout	Critical	Your ZyXEL Device has not received any periodic Upstream Channel Descriptor (UCD) messages from the CMTS within the specified timeout period.
Unicast Ranging Received Abort Response - Re-initializing MAC	Critical	Your ZyXEL Device is online and has sent a periodic Ranging Request (RNG-REQ) message to the CMTS, but it received an Abort Ranging reply instead. Your ZyXEL Device will reset its cable interface and restart the registration process in response. Note that this is not an ethernet MAC frame type.
SYNC Timing Synchronization failure - Loss of Sync	Critical	Your ZyXEL Device had locked on to the downstream channel for a period of time, but then the channel lock was lost and it was unable to be reacquired within five SYNC signal periods. Your ZyXEL Device has reset its cable interface in response to this condition.
No Maintenance Broadcasts for Ranging opportunities received - T2 time-out	Critical	Your ZyXEL Device did not receive a broadcast maintenance opportunity in which to transmit a Ranging Request (RNG-REQ) within the required T2 timeout period (approximately 10 seconds). Your ZyXEL Device will reset its cable interface and restart the registration process.

**Table 9** Event Log: Log Description (continued)

LOG NAME	SEVERITY	DESCRIPTION
Init RANGING Critical Ranging Request Retries exhausted	Critical	Your ZyXEL Device has sent 16 Ranging Request (RNG-REQ) messages without receiving a Ranging Response (RNG-RSP) reply message from your cable operator's CMTS. Your ZyXEL Device will reset its cable interface and restart the registration process. This error message is typically caused by noise on the upstream channel that causes the loss of MAC-layer messages. If your ZyXEL Device cannot raise its upstream channel transmit power to a level that allows successful communication within the maximum timeout period, it resets its cable interface and restarts the registration process.
Received Response to Broadcast Maintenance Request, But no Unicast Maintenance opportunities received - T4 timeout	Critical	Your ZyXEL Device did not received a station maintenance opportunity in which to transmit a Ranging Request (RNG-REQ) message within the required T4 timeout period (30 to 35 seconds). Your ZyXEL Device will reset its cable interface and restart the registration process. Typically, this indicates an occasional, temporary loss of service, but if the problem persists, check for possible service outages or maintenance activity on the part of your cable operator.
No Ranging Response received - T3 time-out	Critical	Your ZyXEL Device sent a Ranging Request (RNG-REQ) message as part of its initial ranging process, but did not receive a Ranging Response (RNG-RSP) message from the CMTS within the required T3 timeout period. Your ZyXEL Device will adjust its upstream channel transmit power and send another RNG-REQ message, up to the maximum of 16 successive attempts, or until it reaches the maximum transmit power level.
Started Unicast Maintenance Ranging - No Response received - T3 time-out	Critical	Your ZyXEL Device is online and has sent a periodic Ranging Request (RNG-REQ) message to the CMTS, without receiving a Ranging Response (RNG-RSP) message from the CMTS within the required T3 timeout period. Your ZyXEL Device will send another RNG-REQ message, up to the maximum of 16 successive attempts.
TFTP Failed - OUT OF ORDER packets	Critical	Your ZyXEL Device attempted to download its DOCSIS compliant configuration file from the TFTP server, but the download failed because the ZyXEL Device received at least one packet that was out of order.
TFTP file complete - but failed Message Integrity check MIC	Critical	Your ZyXEL Device successfully downloaded its configuration file, but the Message Integrity Check (MIC) field sent with the configuration file does not match the one that your ZyXEL Device generated internally after checking the file's contents. This could indicate either that the configuration file was corrupted during file transfer, or that the software tool that generated the configuration file was not performing up to the DOCSIS standard. This message may also indicate that a malicious user is attempting to download their own configuration file as part of a theft-of-service attempt.
TFTP failed - request sent - No Response	Critical	Your ZyXEL Device attempted to download the configuration file from the TFTP server specified by the DHCP server, but the TFTP server has not replied.
TFTP failed - configuration file NOT FOUND	Critical	Your ZyXEL Device attempted to download its configuration file from the TFTP server specified by the DHCP server, but the TFTP server replied that it could not find the requested file.



**Table 9** Event Log: Log Description (continued)

LOG NAME	SEVERITY	DESCRIPTION
ToD request sent - No Response received	Warning	Your ZyXEL Device sent a request to the time-of-day (ToD) server specified by the DHCP server, but it did not receive a reply within the specified timeout period. Your ZyXEL Device defaults to setting its onboard clock to midnight on January 1, 1970. Your ZyXEL Device can now proceed with the registration process without receiving a ToD response, but will continue trying to contact the ToD server every 5 minutes until it receives a valid response.
ToD Response received - Invalid data format	Warning	Your ZyXEL Device received a reply from the ToD server that was specified by the DHCP server. The reply from the ToD server was either an empty datagram or it contained invalid data (the ToD server should send a reply that contains only one 32-bit number that indicates the number of seconds since midnight on January 1, 1900). Please refer to RFC 868, Time Protocol for additional information. The DOCSIS specifications do not allow the use of the Network Time Protocol (NTP) or Simple Network Time Protocol (SNTP) ToD servers to set your ZyXEL Device's system time.
UCC- REQ received with invalid or out of range US channel ID	Error	Your ZyXEL Device has received an Upstream Channel Change Request (UCC-REQ) message from your cable operator's CMTS that contains an upstream channel ID that is either invalid or out of range.
UCC- REQ received unable to send UCC-RSP, no TX opportunity	Error	Your ZyXEL Device has received an Upstream Channel Change Request (UCC-REQ) message from your cable operator's CMTS, but could not reply with an UCC Response message (UCC-RSP) because it could not obtain a transmit timeslot.
US channel wide parameters not set before Burst Descriptors	Critical	Your ZyXEL Device has received an Upstream Channel Descriptor (UCD) message from the CMTS, but it did not set the channel and symbol rate parameters before beginning the set of TLVs (Type Length Value) that specify the burst descriptors for the upstream channel. TLVs are an encoding for three fields: the first field is the type of element, the second field is the length of the element, and the third field is the value of the element.
UCD & SYNC valid - NO MAPS for this channel	Critical	Your ZyXEL Device has received valid Upstream Channel Descriptor (UCD) and SYNC messages from the CMTS, but the upstream channel that is specified in the UCD does not offer your ZyXEL Device any MAP (one slot of the Time Division Multiplexing) minislots in which to transmit.



## 4.1 Overview

This chapter describes the screen you use to enable and configure your DHCP server.

### 4.1.1 What You Can Do in This Chapter

The **DHCP** screen allows you to configure DHCP and IP address settings on the LAN ([Section 4.2 on page 44](#)).

### 4.1.2 What You Need to Know

The following terms and concepts may help as you read through this chapter.

#### IP Address

A static IP is a fixed IP that you configure on the ZyXEL Device. A dynamic IP is not fixed; a DHCP server provides an IP address to an Ethernet device each time it connects to the network. When an Ethernet device is configured to obtain a dynamic IP address from a DHCP server, it is known as a DHCP client.

#### DHCP

DHCP (Dynamic Host Configuration Protocol, RFC 2131 and RFC 2132) allows individual clients to obtain TCP/IP configuration at start-up from a server. You can configure the ZyXEL Device as a DHCP server or disable it on the LAN. When configured as a server, the ZyXEL Device provides the TCP/IP configuration for the DHCP clients. If DHCP service is disabled, you must have another DHCP server on your LAN, or else the computers must be manually configured.

#### IP Pool Setup

You can configure the starting IP address that the ZyXEL Device assigns to clients as well as limit the number of devices which can obtain an IP address from the ZyXEL Device.

## 4.2 DHCP

Click **Basic > DHCP** to display the configuration screen. Use this screen to configure DHCP and IP address settings on the LAN.

**Figure 9** Basic: DHCP

The following table describes the labels in this screen.

**Table 10** Basic: DHCP

LABEL	DESCRIPTION
DHCP	
DHCP Server	Select <b>Yes</b> to set the ZyXEL Device as a DHCP server. Otherwise, select <b>No</b> .
DHCP Server IP	Enter the LAN IP address of the ZyXEL Device in the fields provided.
DHCP Server Mask	Enter the subnet mask associated with the LAN IP address.
Starting Local Address	Specify the first of the contiguous addresses in the IP address pool.
DHCP Pools	Specify the number of IP addresses that the ZyXEL Device will give out to DHCP clients.
Lease Time	Specify the time (in minutes between 1 and 71582788) a DHCP client is allowed to use an assigned IP address. When the lease time expires, the DHCP client is given a new, unused IP address.
Apply	Click <b>Apply</b> to save the settings.

# Advanced

## 5.1 Overview

This chapter describes the Advanced screens you use to configure settings such as IP filtering, MAC filtering and port forwarding.

Use the **Advanced** screens to configure VPN passthrough, enable multicast, filtering, and set up Network Address Translation (NAT) features.

### 5.1.1 What You Can Do in this Chapter

- The **Options** screen allows you to enable or disable advanced features such as multicast and IPSec ([Section 5.2 on page 46](#)).
- The **IP Filtering** screen allows you to block access based on the IP address of a computer on the LAN ([Section 5.3 on page 47](#)).
- The **MAC Filtering** screen allows you to block access based on the MAC address of a computer on the LAN ([Section 5.4 on page 48](#)).
- The **Port Filtering** screen allows you to drop traffic based on service port numbers and protocol types ([Section 5.5 on page 49](#)).
- The **Port Forwarding** screen allows you to forward traffic to certain computers on your network based on the port numbers of incoming traffic ([Section 5.6 on page 50](#)).

### 5.1.2 What You Need to Know

The following terms and concepts may help as you read through this chapter.

#### VPN Pass Through Features

A Virtual Private Network (VPN) is a way to securely connect two networks over the Internet. For example a home network and one in a business office. This requires special equipment on both ends of the connection.

The ZyXEL Device is not one of the endpoints but it does allow traffic from those endpoints to pass through. The ZyXEL Device allows the following types of VPN traffic to pass through:

- IP security (IPSec)
- Point-to-Point Tunneling Protocol (PPTP)

## 5.2 Options

Use the **Options** screen to enable or disable advanced features (such as multicast and IPSec).

**Figure 10** Advanced: Options

Options	
Ipssec PassThrough	<input checked="" type="checkbox"/> Enable
PPTP PassThrough	<input checked="" type="checkbox"/> Enable
Multicast Enable	<input checked="" type="checkbox"/> Enable

The following table describes the labels in this screen.

**Table 11** Advanced: Options

LABEL	DESCRIPTION
Ipssec PassThrough	Select this option to allow the ZyXEL Device to pass through VPN traffic using the IPSec protocol. Clear this option to disallow this type of VPN traffic.
PPTP PassThrough	Select this option to allow the ZyXEL Device to pass through VPN traffic using PPTP. Clear this option to disallow this type of VPN traffic.
Multicast Enable	Select this option to set the ZyXEL Device to forward multicast traffic. The ZyXEL Device acts as an Internet Group Management Protocol (IGMP) proxy and forwards multicast streams to multicast group members on your network.
Apply	Click <b>Apply</b> to save the settings.

### 5.3 IP Filtering

You can set the ZyXEL Device to block access based on the IP address of a computer on the LAN. Computers whose IP addresses are specified in the **IP Filtering** screen are denied access to the ZyXEL Device and the Internet.

Click **Advanced > IP Filtering** to display the configuration screen.

**Figure 11** Advanced: IP Filtering

IP Filtering

Start Address	End Address	Enabled
<input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/>	<input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/>	<input type="checkbox"/>
<input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/>	<input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/>	<input type="checkbox"/>
<input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/>	<input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/>	<input type="checkbox"/>
<input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/>	<input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/>	<input type="checkbox"/>
<input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/>	<input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/>	<input type="checkbox"/>
<input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/>	<input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/>	<input type="checkbox"/>
<input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/>	<input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/>	<input type="checkbox"/>
<input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/>	<input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/>	<input type="checkbox"/>
<input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/>	<input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/> <input type="text" value="0"/>	<input type="checkbox"/>

The following table describes the labels in this screen.

**Table 12** Advanced: IP Filtering

LABEL	DESCRIPTION
Start Address	Enter the IP address of a computer (or the beginning IP address of a specific range of computers) on the LAN that you want the ZyXEL Device to deny access.
End Address	Type the ending IP address of a specific range of users on your LAN that you want the ZyXEL Device to deny access. If you want to exclude only one computer, enter the same IP address as in the <b>Start Address</b> field above.
Enable	Select <b>Enable</b> to block the computer(s) with the IP address(es) from accessing the ZyXEL Device and/or the Internet.
Apply	Click <b>Apply</b> to save the settings.

## 5.4 MAC Filtering

You can set the ZyXEL Device to block access based on the Media Access Control (MAC) address of a computer on the LAN. Every Ethernet device has a unique MAC address. The MAC address is assigned at the factory and consists of six pairs of hexadecimal characters, for example "00:AC:12:00:01:15".

Computers whose MAC addresses are specified in the **MAC Filtering** screen are denied access to the ZyXEL Device and the Internet.

Click **Advanced > MAC Filtering** to display the configuration screen.

**Figure 12** Advanced: MAC Filtering

MAC Address Filters													
	MAC Address							MAC Address					
MAC 01	00	00	00	00	00	00	MAC 02	00	00	00	00	00	00
MAC 03	00	00	00	00	00	00	MAC 04	00	00	00	00	00	00
MAC 05	00	00	00	00	00	00	MAC 06	00	00	00	00	00	00
MAC 07	00	00	00	00	00	00	MAC 08	00	00	00	00	00	00
MAC 09	00	00	00	00	00	00	MAC 10	00	00	00	00	00	00
MAC 11	00	00	00	00	00	00	MAC 12	00	00	00	00	00	00
MAC 13	00	00	00	00	00	00	MAC 14	00	00	00	00	00	00
MAC 15	00	00	00	00	00	00	MAC 16	00	00	00	00	00	00
MAC 17	00	00	00	00	00	00	MAC 18	00	00	00	00	00	00
MAC 19	00	00	00	00	00	00	MAC 20	00	00	00	00	00	00

The following table describes the labels in this screen.

**Table 13** Advanced: MAC Filtering

LABEL	DESCRIPTION
MAC Address	Enter the MAC address of a computer you want the ZyXEL Device to deny access.
Apply	Click <b>Apply</b> to save the changes.



# 5.5 Port Filtering

You can set the ZyXEL Device to drop traffic based on service port numbers and protocol types. This feature allows you to specify the applications (such as MSN and TFTP) the computers on the LAN cannot use. See [Appendix D on page 99](#) for common services.

Click **Advanced > Port Filtering** to display the configuration screen.

**Figure 13** Advanced: Port Filtering

Port Filtering

Start Port	End Port	Protocol	Enabled
1	65535	Both	<input type="checkbox"/>
1	65535	Both	<input type="checkbox"/>
1	65535	Both	<input type="checkbox"/>
1	65535	Both	<input type="checkbox"/>
1	65535	Both	<input type="checkbox"/>
1	65535	Both	<input type="checkbox"/>
1	65535	Both	<input type="checkbox"/>
1	65535	Both	<input type="checkbox"/>
1	65535	Both	<input type="checkbox"/>
1	65535	Both	<input type="checkbox"/>

The following table describes the labels in this screen.

**Table 14** Advanced: Port Filtering

LABEL	DESCRIPTION
Start Port	Enter the beginning service port number whose traffic you want the ZyXEL Device to block.
End Port	Type the ending service port number whose traffic you want the ZyXEL Device to block. If you want to exclude only one service, enter the same service port number as in the <b>Start Port</b> field above.
Protocol	Specify the traffic protocol type. Choices are <b>TCP</b> , <b>UDP</b> and <b>Both</b> .
Enabled	Select <b>Enabled</b> to block traffic based on the selected port number(s) and protocol type.
Apply	Click <b>Apply</b> to save the settings.

## 5.6 Port Forwarding

You can set the ZyXEL Device to forward traffic to certain computers on your network based on the port numbers of incoming traffic. For example, if you set up an FTP server on your local network and you want it be available from the outside your LAN. You can set up a forwarding rule that will send all FTP traffic coming from the WAN to the FTP server on your network. Refer to [Appendix D on page 99](#) for common port numbers and their associated services.

Click **Advanced > Forwarding** to display the configuration screen.

**Figure 14** Advanced: Forwarding

Local IP Address	Start Port	End Port	Protocol	Enabled
0 . 0 . 0 . 0	0	0	Both	<input type="checkbox"/>
0 . 0 . 0 . 0	0	0	Both	<input type="checkbox"/>
0 . 0 . 0 . 0	0	0	Both	<input type="checkbox"/>
0 . 0 . 0 . 0	0	0	Both	<input type="checkbox"/>
0 . 0 . 0 . 0	0	0	Both	<input type="checkbox"/>
0 . 0 . 0 . 0	0	0	Both	<input type="checkbox"/>
0 . 0 . 0 . 0	0	0	Both	<input type="checkbox"/>
0 . 0 . 0 . 0	0	0	Both	<input type="checkbox"/>
0 . 0 . 0 . 0	0	0	Both	<input type="checkbox"/>
0 . 0 . 0 . 0	0	0	Both	<input type="checkbox"/>

The following table describes the labels in this screen.

**Table 15** Advanced: Forwarding

LABEL	DESCRIPTION
Local IP Address	Enter the IP address of a server or computer to which you want to forward traffic incoming on the ports you specify.
Start Port	Type the starting service port number whose traffic you want the ZyXEL Device to forward to the IP address you specified in the <b>Local IP Address</b> field.
End Port	Type the ending service port number whose traffic you want the ZyXEL Device to forward to the IP address you specified in the <b>Local IP Address</b> field. If you want to forward only one service, enter the same service port number as in the <b>Start Port</b> field above.
Protocol	Specify the traffic protocol type. Choices are <b>TCP</b> , <b>UDP</b> and <b>Both</b> .
Enabled	Select <b>Enabled</b> to forward traffic based on the selected port number(s) and protocol type.
Apply	Click <b>Apply</b> to save the settings.

# Wireless LAN


## 6.1 Overview

This chapter discusses how to configure the wireless network settings in your ZyXEL Device.

Note: This chapter is only applicable to the P-974HW model.

The following figure provides an example of a wireless network.

**Figure 15** Example of a Wireless Network



The wireless network is the part in the blue circle. In this wireless network, devices **A** and **B** use the access point (**AP**) to interact with the other devices (such as the printer) or with the Internet. Your ZyXEL Device is the AP.

Every wireless network must follow these basic guidelines.

- Every device in the same wireless network must use the same SSID.

The SSID is the name of the wireless network. It stands for Service Set IDentity.

- If two wireless networks overlap, they should use a different channel.

Like radio stations or television channels, each wireless network uses a specific channel, or frequency, to send and receive information.

- Every device in the same wireless network must use security compatible with the AP.

Security stops unauthorized devices from using the wireless network. It can also protect the information that is sent in the wireless network.

## 6.1.1 What You Need to Know

The following terms and concepts may help as you read through this chapter.

### SSID

Normally, the ZyXEL Device acts like a beacon and regularly broadcasts the SSID in the area. You can hide the SSID instead, in which case the ZyXEL Device does not broadcast the SSID. In addition, you should change the default SSID to something that is difficult to guess.

This type of security is fairly weak, however, because there are ways for unauthorized wireless devices to get the SSID. In addition, unauthorized wireless devices can still see the information that is sent in the wireless network.

### MAC Address Filter

Every device that can use a wireless network has a unique identification number, called a MAC address.<sup>1</sup> A MAC address is usually written using twelve hexadecimal characters<sup>2</sup>; for example, 00A0C5000002 or 00:A0:C5:00:00:02. To get the MAC address for each device in the wireless network, see the device's User's Guide or other documentation.

You can use the **Access Control** screen to tell the ZyXEL Device which devices are allowed or not allowed to use the wireless network. If a device is allowed to use the wireless network, it still has to have the correct information (SSID, channel, and security). If a device is not allowed to use the wireless network, it does not matter if it has the correct information.

This type of security does not protect the information that is sent in the wireless network. Furthermore, there are ways for unauthorized wireless devices to get the

- 
1. Some wireless devices, such as scanners, can detect wireless networks but cannot use wireless networks. These kinds of wireless devices might not have MAC addresses.
  2. Hexadecimal characters are 0, 1, 2, 3, 4, 5, 6, 7, 8, 9, A, B, C, D, E, and F.

MAC address of an authorized device. Then, they can use that MAC address to use the wireless network.

## User Authentication

You can make every user log in to the wireless network before they can use it. This is called user authentication. However, every device in the wireless network has to support IEEE 802.1x to do this.

You need to configure a RADIUS server to set up user names and passwords for your users.

Unauthorized wireless devices can still see the information that is sent in the wireless network, even if they cannot use the wireless network. Furthermore, there are ways for unauthorized wireless users to get a valid user name and password. Then, they can use that user name and password to use the wireless network.

## Encryption

Wireless networks can use encryption to protect the information that is sent in the wireless network. Encryption is like a secret code. If you do not know the secret code, you cannot understand the message.

The types of encryption you can choose depend on the type of authentication. (See [Section on page 53](#) for information about this.)

**Table 16** Types of Encryption for Each Type of Authentication

	NO AUTHENTICATION	RADIUS SERVER
Weakest	None	IEEE 802.1x
	Static WEP	IEEE 802.1x + Static WEP
	WPA-PSK	WPA
Strongest	WPA2-PSK	WPA2

For example, if the wireless network has a RADIUS server, you can choose **IEEE 802.1x**, **IEEE 802.1x + WEP**, **WPA** or **WPA2**. If users do not log in to the wireless network, you can choose **WEP**, **WPA-PSK**, or **WPA2-PSK**.

Usually, you should set up the strongest encryption that every device in the wireless network supports. For example, suppose you have a wireless network with the ZyXEL Device. The ZyXEL Device does not have a local user database, and you do not have a RADIUS server. Therefore, there is no authentication. Suppose the wireless network has two devices. Device A only supports WEP, and device B supports WEP and WPA. Therefore, you should set up **WEP** in the wireless network.

Note: It is recommended that wireless networks use **WPA-PSK**, **WPA**, or stronger encryption. IEEE 802.1x and WEP encryption are better than none at all, but it is still possible for unauthorized wireless devices to figure out the original information pretty quickly.

Many types of encryption use a key to protect the information in the wireless network. The longer the key, the stronger the encryption. Every device in the wireless network must have the same key.

## 6.2 Basic WLAN Settings

To configure general WLAN settings, click **WLAN > Basic** to display the configuration screen.

**Figure 16** Wireless: Basic

The screenshot shows the '802.11b/g Basic' configuration window. It contains the following settings:

- Wireless MAC Address: 00:03:C9:A4:4D:04
- Network Name (SSID): ZyXEL
- Network Type: Open
- Country: USA
- Channel: 1 (Current : (disabled))
- Interface: Disabled

An 'Apply' button is located at the bottom right of the configuration area.

The following table describes the labels in this screen.

**Table 17** Wireless: Basic

LABEL	DESCRIPTION
802.11b/g Basic	
Wireless MAC Address	This read-only field displays the MAC address of the built-in WLAN card.
Network Name (SSID)	<p>The SSID (Service Set IDentification) is a unique name to identify the ZyXEL Device in the wireless LAN. Wireless stations associating to the ZyXEL Device must have the same SSID.</p> <p>Enter a descriptive name of up to 32 printable characters (including spaces; alphabetic characters are case-sensitive).</p>
Network Type	<p>Select <b>Open</b> to make the SSID visible so a station can obtain the SSID through AP scanning.</p> <p>Select <b>Closed</b> to hide the SSID so a station cannot obtain the SSID through AP scanning.</p>
Country	Select your country location in this field. The number of channels available in the <b>Channel</b> field vary depending on the country location you select in this field.

**Table 17** Wireless: Basic (continued)

LABEL	DESCRIPTION
Channel	The radio frequency used by wireless devices is called a channel.  Select a channel from the drop-down list box. The number of channels available vary depending on what you select in the <b>Country</b> field.
Interface	You should configure wireless security when you enable the wireless LAN. Select <b>Enable</b> to activate the wireless LAN, otherwise select <b>Disable</b> to deactivate the wireless LAN.
Apply	Click <b>Apply</b> to save the settings.

## 6.3 Wireless LAN Security

Wireless security is vital to your network to protect wireless communication between wireless stations, access points and the wired network.

Wireless security methods available on the ZyXEL Device are data encryption, wireless client authentication, restricting access by device MAC address and hiding the ZyXEL Device identity.

### 6.3.1 WEP Encryption

WEP encryption scrambles the data transmitted between the wireless stations and the access points to keep network communications private. It encrypts unicast and multicast communications in a network. Both the wireless stations and the access points must use the same WEP key.

Your ZyXEL Device allows you to configure up to four 64-bit or 128-bit WEP keys but only one key can be enabled at any one time.

Click **Wireless > Security** and select **Disable** in the **WPA**, **WPA-PSK**, **WPA2** and **WPA2-PSK** fields to display the configuration screen.

**Figure 17** Wireless: Security: WEP

**802.11b/g Security**

WPA: Disabled

WPA-PSK: Disabled

WPA2: Disabled

WPA2-PSK: Disabled

WPA/WPA2 Encryption: Disabled

WPA Pre-Shared Key: \*\*\*\*\*

RADIUS Server: 0.0.0.0

RADIUS Port: 1812

RADIUS Key:

Group Key Rotation Interval: 22222222

WPA/WPA2 Re-auth Interval: 3600

WEP Encryption: WEP (128-bit)

Shared Key Authentication: Required

802.1x Authentication: Disabled

Network Key 1:

Network Key 2:

Network Key 3:

Network Key 4:

Current Network Key: 2

PassPhrase:

Apply

The following table describes the WEP encryption related labels in this screen.

**Table 18** Wireless: Security: WEP Encryption

LABEL	DESCRIPTION
RADIUS Server	Enter the IP address of the external authentication server in dotted decimal notation. You only need to configure RADIUS server settings if you enable 802.1x authentication.
RADIUS Port	The default port of the RADIUS server for authentication is <b>1812</b> .  You need not change this value unless your network administrator instructs you to do so with additional information.  You only need to configure RADIUS server settings if you enable 802.1x authentication.
RADIUS Key	Enter a password (up to 31 alphanumeric characters) as the key to be shared between the external authentication server and the access points.  The key is not sent over the network. This key must be the same on the external authentication server and ZyXEL Device.  You only need to configure RADIUS server settings if you enable 802.1x authentication.



**Table 18** Wireless: Security: WEP Encryption (continued)

LABEL	DESCRIPTION
WEP Encryption	<p>WEP (Wired Equivalent Privacy) encrypts data frames before transmitting over the wireless network.</p> <p>Select <b>Disable</b> to allow all wireless stations to communicate with the access points without any data encryption.</p> <p>Select <b>WEP (64-bit)</b> or <b>WEP (128-bit)</b> to use data encryption.</p>
Shared Key Authentication	<p>Select <b>Required</b> to use the selected WEP key for basic wireless authentication.</p> <p>Select <b>Disabled</b> to set the ZyXEL Device not to perform basic wireless authentication with a WEP key.</p> <p><b>Note:</b> You can only configure 802.1x Authentication settings if Shared Key Authentication is set to Disabled.</p>
802.1x Authentication	<p>You must have a RADIUS server when you select this setting. You must also configure the <b>RADIUS Key</b> field in this screen. The RADIUS server must be set up with the same <b>RADIUS Key</b> as the ZyXEL Device. Wireless clients authenticate with the RADIUS server before they can access your wireless network.</p>
Network Key 1.. 4	<p>The WEP keys are used to encrypt data. Both the ZyXEL Device and the wireless stations must use the same WEP key for data transmission.</p> <p>If you want to manually set the WEP keys, enter the key in the field provided.</p> <p>If you chose <b>64-bit WEP</b>, then enter any 5 ASCII characters or 10 hexadecimal characters ("0-9", "A-F").</p> <p>If you chose <b>128-bit WEP</b>, then enter 13 ASCII characters or 26 hexadecimal characters ("0-9", "A-F").</p> <p>The values for the WEP keys must be set up exactly the same on all wireless devices in the same wireless LAN.</p> <p>You can configure all four keys, but only one key can be used at any one time. The default key is <b>Network Key 1</b>.</p>
Current Network Key	Select a key to use for data encryption.
Apply	Click <b>Apply</b> to save your changes back to the ZyXEL Device.

## 6.3.2 Introduction to WPA(2)

Wi-Fi Protected Access (WPA) is a subset of the IEEE 802.11i standard. Key differences between WPA(2) and WEP are user authentication and improved data encryption.

### 6.3.2.1 User Authentication

WPA(2) applies IEEE 802.1x and Extensible Authentication Protocol (EAP) to authenticate wireless clients using an external RADIUS database.

Therefore, if you don't have an external RADIUS server you should use WPA(2)-PSK (WPA -Pre-Shared Key) that only requires a single (identical) password entered into each access point, wireless gateway and wireless client. As long as the passwords match, a client will be granted access to a WLAN.

### 6.3.2.2 Encryption

WPA improves data encryption by using Temporal Key Integrity Protocol (TKIP), Message Integrity Check (MIC) and IEEE 802.1x. WPA2 uses Advanced Encryption Standard (AES) to offer stronger encryption.

- Use WPA security if you have WPA-aware wireless clients and a RADIUS server. WPA has user authentication and improved data encryption over WEP.
- Use WPA-PSK if you have WPA-aware wireless clients but no RADIUS server.
- If you don't have WPA-aware wireless clients, then use WEP key encrypting. A higher bit key offers better security at a throughput trade-off. You can use Passphrase to automatically generate 64-bit or 128-bit WEP keys or manually enter 64-bit or 128-bit WEP keys.

### 6.3.3 WPA/WPA2

Click **Wireless > Security** and select **Enabled** in only the **WPA** or **WPA2** field to display the configuration screen.

**Figure 18** Wireless: Security: WPA

802.11b/g Security	
WPA	Enabled
WPA-PSK	Disabled
WPA2	Disabled
WPA2-PSK	Disabled
WPA/WPA2 Encryption	TKIP
WPA Pre-Shared Key	*****
RADIUS Server	0.0.0.0
RADIUS Port	1812
RADIUS Key	
Group Key Rotation Interval	22222222
WPA/WPA2 Re-auth Interval	3600
WEP Encryption	Disabled
Shared Key Authentication	Required
802.1x Authentication	Disabled
Network Key 1	
Network Key 2	
Network Key 3	
Network Key 4	
Current Network Key	2
PassPhrase	
Apply	

The follow table describes the WPA related labels in this screen.

**Table 19** Wireless: Security: WPA/WPA2

<b>LABEL</b>	<b>DESCRIPTION</b>
WPA/WPA2 Encryption	Select an encryption type.
RADIUS Server	Enter the IP address of the external authentication server in dotted decimal notation.
RADIUS Port	The default port of the RADIUS server for authentication is <b>1812</b> .  You need not change this value unless your network administrator instructs you to do so with additional information.
RADIUS Key	Enter a password (up to 31 alphanumeric characters) as the key to be shared between the external authentication server and the access points.  The key is not sent over the network. This key must be the same on the external authentication server and ZyXEL Device.
Apply	Click <b>Apply</b> to save your changes back to the ZyXEL Device.

### 6.3.4 WPA-PSK/WPA2-PSK

If you don't have an external RADIUS server, you should use WPA(2)-PSK (WPA - Pre-Shared Key). WPA(2)-PSK only requires a single (identical) password entered into each WLAN member. As long as the passwords match, a client will be granted access to the wireless network.

Click **Wireless > Security** and select **Enabled** in the **WPA-PSK** or **WPA2-PSK** field to display the configuration screen as shown.

**Figure 19** Wireless: Security: WPA-PSK

**802.11b/g Security**

WPA	Disabled
WPA-PSK	Disabled
WPA2	Disabled
WPA2-PSK	Enabled
WPA/WPA2 Encryption	AES
WPA Pre-Shared Key	*****
RADIUS Server	0,0,0,0
RADIUS Port	1812
RADIUS Key	
Group Key Rotation Interval	22222222
WPA/WPA2 Re-auth Interval	3600
WEP Encryption	Disabled
Shared Key Authentication	Required
802.1x Authentication	Disabled
Network Key 1	
Network Key 2	
Network Key 3	
Network Key 4	
Current Network Key	2
PassPhrase	

Apply

The follow table describes the WPA related labels in this screen.

**Table 20** Wireless: Security: WPA-PSK

LABEL	DESCRIPTION
WPA-PSK	Select Enabled to activate WPA-PSK wireless LAN security.
WPA/WPA2 Encryption	Select an encryption type.

**Table 20** Wireless: Security: WPA-PSK (continued)

LABEL	DESCRIPTION
WPA Pre-Shared Key	Enter a password (up to 31 alphanumeric characters) as the key to be shared between the external authentication server and the access points.  The key is not sent over the network. This key must be the same on the external authentication server and ZyXEL Device.
Group Key Rotation Interval	This is the rate at which the AP sends a new group key out to all clients. The re-keying process is the WPA equivalent of automatically changing the WEP key for an AP and all stations in a WLAN on a periodic basis. Enter the number of seconds between a key rotation occurs.
Apply	Click <b>Apply</b> to save your changes back to the ZyXEL Device.

## 6.4 Access Control

To change your ZyXEL Device Access Control settings click **Wireless > Access Control**.

Note: Be careful not to list your computer's MAC address and set the **MAC Restrict Mode** field to **Deny** when managing the ZyXEL Device via a wireless connection. This would lock you out.

**Figure 20** Wireless: Access Control

**802.11b/g Access Control**

MAC Restrict Mode: Disabled

MAC Addresses


**Connected Clients**

MAC Address	Age(s)	RSSI(dBm)	IP Addr	Host Name
ERROR retrieving list of wireless clients.				

Apply

The following table describes the labels in this screen.

**Table 21** Wireless: Access Control

LABEL	DESCRIPTION
802.11b/g Access Control	
MAC Restrict Mode	<p>Enable/disable wireless access control and/or set action for the list of MAC addresses in the <b>MAC Address</b> table.</p> <p>Select <b>Deny</b> to block access to the router, MAC addresses not listed will be allowed to access the ZyXEL Device. Select <b>Allow</b> to permit access to the router, MAC addresses not listed will be denied access to the ZyXEL Device.</p> <p>Select <b>Disabled</b> to deactivate this feature.</p>
MAC Address	Enter the MAC addresses in a valid MAC address format, that is, six hexadecimal character pairs, for example, 12:34:56:78:9a:bc of the wireless stations that are allowed or denied access to the ZyXEL Device in these address fields.
Apply	Click <b>Apply</b> to save the settings.
Connected Clients	The table below displays the list of wireless LAN client(s) that is currently connect to the ZyXEL Device.
MAC Address	<p>This field displays the MAC (Media Access Control) address of an associated wireless station.</p> <p>Every Ethernet device has a unique MAC address. The MAC address is assigned at the factory and consists of six pairs of hexadecimal characters, for example, 00:A0:C5:00:00:02.</p>
Age(s)	This field displays the time (in seconds) since the wireless device connected to the ZyXEL Device.
RSSI (dBm)	<p>Received Signal Strength Indicator (RSSI) measures the strength of the signals received. When the received signal strength is below the specified RSSI value, the wireless device sends a clear-to-send (CTS) signal.</p> <p>This field displays the RSSI value for a wireless device.</p>
IP Addr	This field displays the IP address associated to the MAC address above.
Host Name	This is the name of the host computer.

# Maintenance

## 7.1 Overview

This chapter shows you how to change the ZyXEL Device administrator login password and perform device connection tests.


### 7.1.1 What You Can Do in this Chapter

- The **Security** screen allows you to change the password used for accessing the ZyXEL Device ([Section 7.2 on page 63](#)).
- The **Diagnostics** screen allows you to ping a device to test the connection or to perform a trace route ([Section 7.3 on page 64](#)).
- The **Band** screen allow you to configure frequency bands for faster downstream channel scanning for Internet access ([Section 7.4 on page 66](#)).

## 7.2 Security

It is highly recommended that you periodically change the password for accessing the ZyXEL Device. If you didn't change the default one after you logged in or you want to change to a new password again, then click **Maintenance > Security** to display the screen as shown next.

**Figure 21** Maintenance: Security



The screenshot shows the 'Security' configuration page. It has a title bar 'Security' and four text input fields for password management: 'Password Change User ID', 'New Password', 'Re-Enter New Password', and 'Current User ID Password'. At the bottom, there is a 'Restore Factory Defaults' label followed by two radio buttons: 'Yes' and 'No', with 'No' being the selected option.

The following table describes the labels in this screen.

**Table 22** Maintenance: Security

LABEL	DESCRIPTION
Password Change User ID	Enter the login username whose password you want to change.
New Password	Type the new password in this field.  Passwords may be up to 16 characters in length and must be alphanumeric (a-z, A-Z, 0-9), no other characters are allowed.
Re-enter New Password	Type the new password again in this field.
Current User ID Password	Type the default password or the existing password (associated with the username you enter above) you use to access the system in this field.
Restore to Factory Defaults	Select <b>Yes</b> to restore the ZyXEL Device settings to the factory defaults. Otherwise, select <b>No</b> to keep your ZyXEL Device settings.
Apply	Click <b>Apply</b> to save your changes.

## 7.3 Diagnostics

Use the **Diagnostics** screen to ping a device to test the connection or to perform a trace route.

Click **Maintenance > Diagnostic** to display the screen, then select either **Ping** or **Traceroute** from the **Select Utility** menu to choose a test.

**Figure 22** Maintenance: Diagnostic (Ping)

Select Utility: Ping

**Ping Test Parameters**

Ping Target:  IP address or Name

Ping Size:  bytes

No. of Pings:

Ping Interval:  ms

**Results**

**Caution:**  
To get an update of the results you must REFRESH the page.



The following table describes the labels in this screen.

**Table 23** Maintenance: Diagnostics (Ping)

LABEL	DESCRIPTION
Select Utility	Select either <b>Ping</b> or <b>Traceroute</b> from the <b>Select Utility</b> menu to choose a test. The screen changes accordingly.
Ping Test Parameters	
Ping Target	Type the IP address or domain name (such as www.example.com) of a device that you want to ping in order to test a connection.
Ping Size	Specify the size of the ping packet the ZyXEL Device is to send. The default is 64 bytes (56 bytes of data plus 8 bytes for the header). If you need to determine the Maximum Transmission Unit (MTU) size TCP/IP connection, change this setting. Otherwise leave it as the default.
No. of Pings	Specify the number of ping packets the ZyXEL Device sends to the target device.
Ping Interval	Specify the time (in milliseconds) the ZyXEL Device sends a ping packet.
Start Test	Click <b>Start Test</b> to begin the ping test.
Abort Test	Click <b>Abort Test</b> to stop the ping test.
Clear Results	Click <b>Clear Results</b> to clear the <b>Results</b> text box.
Results	This read-only text box displays the ping test results.

**Figure 23** Maintenance: Diagnostic (Traceroute)

Select Utility: Traceroute

---

**Traceroute Parameters**

Target  IP address or Name

Max Hops


Data Size  bytes

Base Port

Resolve Host  ▼

Start Test Abort Test Clear Results

**Results**

 **Caution:**  
To get an update of the results you must REFRESH the page.

The following table describes the labels in this screen.

**Table 24** Maintenance: Diagnostics (Traceroute)

LABEL	DESCRIPTION
Select Utility	Select either <b>Ping</b> or <b>Traceroute</b> from the <b>Select Utility</b> menu to choose a test. The screen changes accordingly.
Traceroute Test Parameters	
Target	Type the IP address or domain name (such as www.example.com) of a device that you want to traceroute in order to test a connection.
Max Hops	Specify the maximum number of hops the traceroute takes before the process ends. A hop is connection from one router or intermediate device to another on a network. The more hops there are, the longer it takes for data to reach its destination.
Data Size	Specify the number of data packet bytes the ZyXEL Device sends on the traceroute. The default is 40 bytes (32 bytes of data plus 8 bytes for the header). If you need to determine the Maximum Transmission Unit (MTU) size TCP/IP connection, change this setting. Otherwise leave it as the default.
Base Port	This field is not enabled as of this writing.
Resolve Host	Select <b>On</b> to resolved all IP addresses returned by the traceroute to their domain names.
Start Test	Click <b>Start Test</b> to begin the ping test.
Abort Test	Click <b>Abort Test</b> to stop the ping test.
Clear Results	Click <b>Clear Results</b> to clear the <b>Results</b> text box.
Results	This read-only text box displays the ping test results.

## 7.4 Band

Use the **Band** screen to configure frequency bands for faster downstream channel scanning for Internet access.

Click **Maintenance > Band** to display the configuration screen.

**Figure 24** Maintenance: Band

Plan	Start Channel	End Channel	Frequency offset
Default ▼	0	0	0
Default ▼	0	0	0
Default ▼	0	0	0
Default ▼	0	0	0
Default ▼	0	0	0

The following table describes the labels in this screen.

**Table 25** Maintenance: Band

LABEL	DESCRIPTION
Plan	<p>Select a pre-defined band plan setting you wish to configure. The band plans are:</p> <ul style="list-style-type: none"> <li>• <b>EIA</b>: EIA-542 Cable Television Channel Identification Plan</li> <li>• <b>HRC</b>: Harmonic -Related Carrier Frequency Plan</li> <li>• <b>BG</b>: Europe Standard B + G Frequency Plan</li> <li>• <b>OIRT</b>: OIRT Standard D Frequency Plan</li> <li>• <b>EURO</b>: 250 kHz incremental Non-Standard Frequency Plan</li> </ul>
Start Channel	<p>Select scan plan <b>EIA</b>, <b>HRC</b>, <b>OIRT</b> or <b>BG</b> and enter the first channel ID in the range you want the ZyXEL Device to scan.</p> <p>For the <b>EURO</b> plan enter the starting frequency (lowest) you want the ZyXEL Device to scan.</p>
End Channel	<p>Select scan plan <b>EIA</b>, <b>HRC</b>, <b>OIRT</b> or <b>BG</b> and enter the last channel ID in the range you want the ZyXEL Device to scan.</p> <p>For the <b>EURO</b> plan enter the last frequency (highest) you want the ZyXEL Device to scan.</p>
Frequency Offset	<p>This field is applicable when you select <b>EURO</b> in the <b>Plan</b> field.</p> <p>Enter the offset. For example if you enter 50000, the ZyXEL Device will scan frequencies from the starting frequency to the last frequency in 50000 Hz increments.</p>
Apply	Click <b>Apply</b> to save the settings.



---

# PART II

## Appendices and Index

---

Product Specifications (71)

Sample Configurations (77)

Setting up Your Computer's IP Address  
(81)

Common Services (99)

Legal Information (103)

Customer Support (107)

Index (113)



# Product Specifications

See also the Introduction chapter for a general overview of the key features.

## Firmware Features

**Table 26** Firmware Features

FEATURE	DESCRIPTION
High Speed Internet Access	<p>The ZyXEL Device supports transmission speeds of up to 43 Mbps upstream and 30 Mbps downstream. Actual speeds attained depend on your cable operator's CMTS (Cable Modem Termination System).</p> <p><b>Note:</b> The standard your cable operator supports determines the maximum upstream and downstream speeds attainable. Actual speeds attained depend on the distance from the cable operator's central office, noise, and so on.</p>
Network Address Translation (NAT)	Each computer on your network must have its own unique IP address. Use NAT to convert your public IP address(es) to multiple private IP addresses for the computers on your network.
Port Forwarding	If you have a server (mail or web server for example) on your network, you can use this feature to let people access it from the Internet.
DHCP (Dynamic Host Configuration Protocol)	Use this feature to have the ZyXEL Device assign IP addresses, an IP default gateway and DNS servers to computers on your network.
Management	Use the built in web configurator to configure and diagnose your ZyXEL Device.
IP Multicast	IP multicast is used to send traffic to a specific group of computers. The ZyXEL Device supports version 1 IGMP (Internet Group Management Protocol) used to join multicast groups (see RFC 2236).
Wireless Functionality (P-974HW Only)	Allow the IEEE 802.11b and/or IEEE 802.11g wireless clients to connect to the ZyXEL Device wirelessly. Enable wireless security (WEP, WPA(2), WPA(2)-PSK) and/or MAC filtering to protect your wireless network.

IEEE 802.11b/g data rate and modulation are as follows:

**Table 27** IEEE802.11b/g

DATA RATE (MBPS)	MODULATION
1	DBPSK (Differential Binary Phase Shift Keyed)
2	DQPSK (Differential Quadrature Phase Shift Keying)
5.5 / 11	CCK (Complementary Code Keying)
6/9/12/18/24/36/48/54	OFDM (Orthogonal Frequency Division Multiplexing)

## Device Specification

**Table 28** Device Specifications

NETWORK	
Default IP Address	192.168.1.1:8080
Default Subnet Mask	255.255.255.0 (24 bits)
Default Administrator Username	webadmin
Default Administrator Password	1234
DHCP	Relay - Supports up to five (5) IP addresses from a remote DHCP server.  Server - Configurable IP address pool and limits on number of DHCP clients.
Cable Modem Standard	DOCSIS 2.0 Compliant  Cable Home 1.1 Compliant
Ethernet Ports	Four auto-negotiating, auto MDI/MDI-X 10/100 Mbps RJ-45 Ethernet ports.
USB Port	One USB 2.0 port for connecting to the P-974H/HW.
Management	SNMP v1, v2, and v3. Remote status monitoring  Web Configurator  FTP  Text based configuration file for easy deployment  TACACS+ server support



**Table 28** Device Specifications (continued)

Wireless (P-974HW Only)	WEP, WPA, WPA2, WPA-PSK, WPA2-PSK  RADIUS server authentication  MAC Filter  IEEE 802.1x authentication  Bridging Mode
External Antenna	Detachable 3dBi antenna
<b>SECURITY</b>	
Type supported	BPI and BPI+.
Packet filter	DOCSIS packet filter.
Alerts and Logs	Logging: gateway activities, hacking attempts  Alerts: Email alerts based on filtering
<b>PHYSICAL</b>	
Dimensions	(197 W) x (143 D) x (31 H) mm
Operation Temperature	0° C ~ 40° C
Storage Temperature	-30° ~ 60° C
Operation Humidity	20% ~ 90% RH
Storage Humidity	10% ~ 90% RH
<b>DOWNSTREAM CHANNEL</b>	
Center Frequency	91 to 857 MHZ
Channel Bandwidth	6 Mhz
Input Impedance	75 ohms (nominal)
Modulation	64 QAM or 256 QAM
Maximum Data rate	30 Mbps for 64 QAM 43Mbps for 256 QAM
Symbol Rates	5.057 Msym/s for 64 QAM 5.361 Msym/s for 256 QAM
Operating Level	-15 to +15 dBmV
<b>UPSTREAM CHANNEL</b>	
Frequency Range	5 to 42 Mhz
Bandwidth	200 Khz/400 Khz/800 Khz 1.6 Mhz/3.2 Mhz/6.4* Mhz
Output Impedance	75 ohms (nominal)
Modulation	8*/16/32*/64*/128* QAM or QPSK

**Table 28** Device Specifications (continued)

Maximum Data Rate	30 Mbps
Symbol Rates	160, 320, 640, 1280, 2560 and 5120* Ksym/s
Operating Level	TDMA:  +8 to +54 dBmV (32 QAM, 64QAM)  +8 to +55 dBmV (8 QAM, 16QAM)  +8 to +58 dBmV (QPSK)  S-CDMA:  +8 to +53 dBmV (all modulation types)
<b>OPERATING SYSTEM COMPATIBILITY</b>	
Ethernet Connection	Windows 95/98se/2000/ ME/XP, Macintosh, Linux and UNIX
USB Connection	Window 98sec/2000/ME/XP

## Power Adaptor Specifications

**Table 29** P-974H/HW Power Adaptor Specifications

<b>NORTH AMERICAN PLUG STANDARDS</b>	
AC Power Adapter Model	MU18-2120150-A1
Input Power	100~240 Volts AC, 50-60 Hz, 0.6A
Output Power	12 Volts DC, 1.5A 18W
Power Consumption	12W Max
Safety Standards	UL 60950-1 First Edition CSA C22.2 No. 60950-1-03 First Edition
<b>EUROPEAN PLUG STANDARDS</b>	
AC Power Adapter Model	MU18-2120150-C5
Input Power	100~240 Volts AC, 50-60 Hz, 0.6A
Output Power	12 Volts DC, 1.5A 18W
Power Consumption	12W Max
Safety Standards	EN/IEC 60950-1:2001
<b>UNITED KINGDOM PLUG STANDARDS</b>	
AC Power Adapter Model	MU18-2120150-B2
Input Power	100~240 Volts AC, 50-60 Hz, 0.6A
Output Power	12 Volts DC, 1.5A 18W

**Table 29** P-974H/HW Power Adaptor Specifications (continued)

Power Consumption	12W Max
Safety Standards	EN/IEC 60950-1:2001
<b>AUSTRALIA PLUG STANDARDS</b>	
AC Power Adapter Model	MU18-2120150-A3
Input Power	100~240 Volts AC, 50-60 Hz, 0.6A
Output Power	12 Volts DC, 1.5A 18W
Power Consumption	12W Max
Safety Standards	EN 60950:2000 IEC 60950-1:2001



# Sample Configurations


## 7.5 Overview

The following are some sample configurations for your ZyXEL Device. The values used in these samples are for example purposes only; please use the values provided by your ISP where appropriate.

## 7.6 Connecting to the ZyXEL Device with Telnet

Before you can use these sample configurations, you must first connect to the ZyXEL Device with Telnet.

- 1 Open your Command Line prompt or terminal application.
- 2 Telnet to 198.162.1.1.



```
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.

C:\Documents and Settings\13435>telnet 192.168.1.1
```

- 3 Login as admin (default password "1234").

After connecting to the ZyXEL Device, you can enter any of the commands in the following samples. Be sure to customize them first.

## 7.6.1 Set Static IP Only

To set only a static IP address, enter the following commands:

```
> defaults
> ip_sharing false
> dhcp_enable false
> dhcp_server 10.13.17.1 255.255.255.0
> static_ip 10.13.17.1 255.255.255.0
> dns_server 172.21.3.88 172.23.5.1 172.23.5.2
> rip_enable true
> rip2_md5 true
> rip2_keyid 1
> rip2_keyststr david
> save
> reset
```

Change the settings according to the information provided by your ISP or network administrator.

## 7.6.2 Set Static IP with Public DHCP

To set a static IP address with a public DHCP server, enter the following commands:

```
> defaults
> ip_sharing false
> dhcp_enable true
> dhcp_server 10.13.17.1 255.255.255.0
> dhcp_pool 10.13.17.2 20
> static_ip 10.13.17.1 255.255.255.0
> dns_server 172.21.3.88 172.23.5.1 172.23.5.2
> rip_enable true
> rip2_md5 true
> rip2_keyid 1
> rip2_keyststr david
> save
> reset
```

Change the settings according to the information provided by your ISP or network administrator.

## 7.6.3 Set Static IP with NAT

To set a static IP address with NAT, enter the following commands:

```
> defaults
> ip_sharing false
> dhcp_enable false
> dhcp_server 192.168.1.1 255.255.255.0
> static_ip 10.13.17.1 255.255.255.0
> dns_server 172.21.3.88 172.23.5.1 172.23.5.2
> rip_enable true
> rip2_md5 true
> rip2_keyid 1
> rip2_keyststr david
> save
> reset
```

Change the settings according to the information provided by your ISP or network administrator.

## 7.6.4 Set Static IP with NAT and Private DHCP

To set a static IP address with NAT and a private DHCP server, enter the following commands:

```
> defaults
> ip_sharing false
> dhcp_enable true
> dhcp_server 192.168.1.1 255.255.255.0
> dhcp_pool 192.168.1.2 20
> static_ip 10.13.17.1 255.255.255.0
> dns_server 172.21.3.88 172.23.5.1 172.23.5.2
> rip_enable true
> rip2_md5 true
> rip2_keyid 1
> rip2_keyststr david
> save
> reset
```

Change the settings according to the information provided by your ISP or network administrator.

## 7.6.5 Set Bridge Mode

To set the ZyXEL Device to bridge mode, enter the following commands:

```
> defaults
> router_enable false
> save
> reset
```

## 7.6.6 Set Default IP Sharing / RG Mode

To set the ZyXEL Device to its default IP Sharing / RG mode, enter the following commands:

```
> defaults
> save
> reset
```

Change the settings according to the information provided by your ISP or network administrator.



# Setting up Your Computer's IP Address

All computers must have a 10M or 100M Ethernet adapter card and TCP/IP installed.

Windows 95/98/Me/NT/2000/XP, Macintosh OS 7 and later operating systems and all versions of UNIX/LINUX include the software components you need to install and use TCP/IP on your computer. Windows 3.1 requires the purchase of a third-party TCP/IP application package.

TCP/IP should already be installed on computers using Windows NT/2000/XP, Macintosh OS 7 and later operating systems.


After the appropriate TCP/IP components are installed, configure the TCP/IP settings in order to "communicate" with your network.

If you manually assign IP information instead of using dynamic assignment, make sure that your computers have IP addresses that place them in the same subnet as the ZyXEL Device's LAN port.

## Windows 95/98/Me

Click **Start, Settings, Control Panel** and double-click the **Network** icon to open the **Network** window.

**Figure 25** Windows 95/98/Me: Network: Configuration



### Installing Components

The **Network** window **Configuration** tab displays a list of installed components. You need a network adapter, the TCP/IP protocol and Client for Microsoft Networks.

If you need the adapter:

- 1 In the **Network** window, click **Add**.
- 2 Select **Adapter** and then click **Add**.
- 3 Select the manufacturer and model of your network adapter and then click **OK**.

If you need TCP/IP:

- 1 In the **Network** window, click **Add**.
- 2 Select **Protocol** and then click **Add**.

- 3 Select **Microsoft** from the list of **manufacturers**.
- 4 Select **TCP/IP** from the list of network protocols and then click **OK**.


If you need Client for Microsoft Networks:

- 1 Click **Add**.
- 2 Select **Client** and then click **Add**.
- 3 Select **Microsoft** from the list of manufacturers.
- 4 Select **Client for Microsoft Networks** from the list of network clients and then click **OK**.
- 5 Restart your computer so the changes you made take effect.

## Configuring


- 1 In the **Network** window **Configuration** tab, select your network adapter's TCP/IP entry and click **Properties**
- 2 Click the **IP Address** tab.
  - If your IP address is dynamic, select **Obtain an IP address automatically**.
  - If you have a static IP address, select **Specify an IP address** and type your information into the **IP Address** and **Subnet Mask** fields.

**Figure 26** Windows 95/98/Me: TCP/IP Properties: IP Address



- 3 Click the **DNS** Configuration tab.
  - If you do not know your DNS information, select **Disable DNS**.
  - If you know your DNS information, select **Enable DNS** and type the information in the fields below (you may not need to fill them all in).

**Figure 27** Windows 95/98/Me: TCP/IP Properties: DNS Configuration



- 4 Click the **Gateway** tab.
  - If you do not know your gateway's IP address, remove previously installed gateways.
  - If you have a gateway IP address, type it in the **New gateway field** and click **Add**.
- 5 Click **OK** to save and close the **TCP/IP Properties** window.
- 6 Click **OK** to close the **Network** window. Insert the Windows CD if prompted.
- 7 Turn on your ZyXEL Device and restart your computer when prompted.

## Verifying Settings


- 1 Click **Start** and then **Run**.
- 2 In the **Run** window, type "winipcfg" and then click **OK** to open the **IP Configuration** window.
- 3 Select your network adapter. You should see your computer's IP address, subnet mask and default gateway.

## Windows 2000/NT/XP

The following example figures use the default Windows XP GUI theme.

- 1 Click **start** (**Start** in Windows 2000/NT), **Settings**, **Control Panel**.

**Figure 28** Windows XP: Start Menu




- 2 In the **Control Panel**, double-click **Network Connections** (**Network and Dial-up Connections** in Windows 2000/NT).

**Figure 29** Windows XP: Control Panel




- 3 Right-click **Local Area Connection** and then click **Properties**.

**Figure 30** Windows XP: Control Panel: Network Connections: Properties



- 4 Select **Internet Protocol (TCP/IP)** (under the **General** tab in Win XP) and then click **Properties**.


**Figure 31** Windows XP: Local Area Connection Properties



- 5 The **Internet Protocol TCP/IP Properties** window opens (the **General** tab in Windows XP).

- If you have a dynamic IP address click **Obtain an IP address automatically**.
- If you have a static IP address click **Use the following IP Address** and fill in the **IP address**, **Subnet mask**, and **Default gateway** fields.
- Click **Advanced**.

**Figure 32** Windows XP: Internet Protocol (TCP/IP) Properties




- 6 If you do not know your gateway's IP address, remove any previously installed gateways in the **IP Settings** tab and click **OK**.

Do one or more of the following if you want to configure additional IP addresses:

- In the **IP Settings** tab, in IP addresses, click **Add**.
- In **TCP/IP Address**, type an IP address in **IP address** and a subnet mask in **Subnet mask**, and then click **Add**.
- Repeat the above two steps for each IP address you want to add.
- Configure additional default gateways in the **IP Settings** tab by clicking **Add** in **Default gateways**.
- In **TCP/IP Gateway Address**, type the IP address of the default gateway in **Gateway**. To manually configure a default metric (the number of transmission hops), clear the **Automatic metric** check box and type a metric in **Metric**.
- Click **Add**.
- Repeat the previous three steps for each default gateway you want to add.

- Click **OK** when finished.

**Figure 33** Windows XP: Advanced TCP/IP Properties




**7** In the **Internet Protocol TCP/IP Properties** window (the **General** tab in Windows XP):

- Click **Obtain DNS server address automatically** if you do not know your DNS server IP address(es).
- If you know your DNS server IP address(es), click **Use the following DNS server addresses**, and type them in the **Preferred DNS server** and **Alternate DNS server** fields.



If you have previously configured DNS servers, click **Advanced** and then the **DNS** tab to order them.

**Figure 34** Windows XP: Internet Protocol (TCP/IP) Properties



- 8 Click **OK** to close the **Internet Protocol (TCP/IP) Properties** window.
- 9 Click **Close** (**OK** in Windows 2000/NT) to close the **Local Area Connection Properties** window.
- 10 Close the **Network Connections** window (**Network and Dial-up Connections** in Windows 2000/NT).
- 11 Turn on your ZyXEL Device and restart your computer (if prompted).


## Verifying Settings

- 1 Click **Start**, **All Programs**, **Accessories** and then **Command Prompt**.
- 2 In the **Command Prompt** window, type "ipconfig" and then press [ENTER]. You can also open **Network Connections**, right-click a network connection, click **Status** and then click the **Support** tab.

## Macintosh OS 8/9


- 1 Click the **Apple** menu, **Control Panel** and double-click **TCP/IP** to open the **TCP/IP Control Panel**.

**Figure 35** Macintosh OS 8/9: Apple Menu



- 2 Select **Ethernet built-in** from the **Connect via** list.

**Figure 36** Macintosh OS 8/9: TCP/IP



- 3 For dynamically assigned settings, select **Using DHCP Server** from the **Configure:** list.
- 4 For statically assigned settings, do the following:
  - From the **Configure** box, select **Manually**.
  - Type your IP address in the **IP Address** box.
  - Type your subnet mask in the **Subnet mask** box.
  - Type the IP address of your ZyXEL Device in the **Router address** box.
- 5 Close the **TCP/IP Control Panel**.
- 6 Click **Save** if prompted, to save changes to your configuration.
- 7 Turn on your ZyXEL Device and restart your computer (if prompted).


## Verifying Settings

Check your TCP/IP properties in the **TCP/IP Control Panel** window.

## Macintosh OS X


- 1 Click the **Apple** menu, and click **System Preferences** to open the **System Preferences** window.

**Figure 37** Macintosh OS X: Apple Menu



- 2 Click **Network** in the icon bar.
  - Select **Automatic** from the **Location** list.
  - Select **Built-in Ethernet** from the **Show** list.
  - Click the **TCP/IP** tab.
- 3 For dynamically assigned settings, select **Using DHCP** from the **Configure** list.

**Figure 38** Macintosh OS X: Network



- 4 For statically assigned settings, do the following:

- From the **Configure** box, select **Manually**.
  - Type your IP address in the **IP Address** box.
  - Type your subnet mask in the **Subnet mask** box.
  - Type the IP address of your ZyXEL Device in the **Router address** box.
- 5 Click **Apply Now** and close the window.
  - 6 Turn on your ZyXEL Device and restart your computer (if prompted).

## Verifying Settings

Check your TCP/IP properties in the **Network** window.

## Linux

This section shows you how to configure your computer's TCP/IP settings in Red Hat Linux 9.0. Procedure, screens and file location may vary depending on your Linux distribution and release version.


Note: Make sure you are logged in as the root administrator.

## Using the K Desktop Environment (KDE)

Follow the steps below to configure your computer IP address using the KDE.

- 1 Click the Red Hat button (located on the bottom left corner), select **System Setting** and click **Network**.

**Figure 39** Red Hat 9.0: KDE: Network Configuration: Devices




- 2 Double-click on the profile of the network card you wish to configure. The **Ethernet Device General** screen displays as shown.

**Figure 40** Red Hat 9.0: KDE: Ethernet Device: General



- If you have a dynamic IP address click **Automatically obtain IP address settings with** and select **dhcp** from the drop down list.
  - If you have a static IP address click **Statically set IP Addresses** and fill in the **Address**, **Subnet mask**, and **Default Gateway Address** fields.
- 3 Click **OK** to save the changes and close the **Ethernet Device General** screen.
  - 4 If you know your DNS server IP address(es), click the **DNS** tab in the **Network Configuration** screen. Enter the DNS server information in the fields provided.

**Figure 41** Red Hat 9.0: KDE: Network Configuration: DNS



- 5 Click the **Devices** tab.

- 6 Click the **Activate** button to apply the changes. The following screen displays. Click **Yes to save the changes in all screens**.

**Figure 42** Red Hat 9.0: KDE: Network Configuration: Activate



- 7 After the network card restart process is complete, make sure the **Status** is **Active** in the **Network Configuration** screen.

## Using Configuration Files

Follow the steps below to edit the network configuration files and set your computer IP address.

- 1 Assuming that you have only one network card on the computer, locate the `ifconfig-eth0` configuration file (where `eth0` is the name of the Ethernet card). Open the configuration file with any plain text editor.
  - If you have a dynamic IP address, enter **dhcp** in the `BOOTPROTO=` field. The following figure shows an example.

**Figure 43** Red Hat 9.0: Dynamic IP Address Setting in `ifconfig-eth0`

```
DEVICE=eth0
ONBOOT=yes
BOOTPROTO=dhcp
USERCTL=no
PEERDNS=yes
TYPE=Ethernet
```

- If you have a static IP address, enter **static** in the `BOOTPROTO=` field. Type `IPADDR=` followed by the IP address (in dotted decimal notation) and type `NETMASK=` followed by the subnet mask. The following example shows an example where the static IP address is 192.168.1.10 and the subnet mask is 255.255.255.0.

**Figure 44** Red Hat 9.0: Static IP Address Setting in `ifconfig-eth0`

```
DEVICE=eth0
ONBOOT=yes
BOOTPROTO=static
IPADDR=192.168.1.10
NETMASK=255.255.255.0
USERCTL=no
PEERDNS=yes
TYPE=Ethernet
```

- 2 If you know your DNS server IP address(es), enter the DNS server information in the `resolv.conf` file in the `/etc` directory. The following figure shows an example where two DNS server IP addresses are specified.

**Figure 45** Red Hat 9.0: DNS Settings in `resolv.conf`

```
nameserver 172.23.5.1
nameserver 172.23.5.2
```

- 3 After you edit and save the configuration files, you must restart the network card. Enter `./network restart` in the `/etc/rc.d/init.d` directory. The following figure shows an example.

**Figure 46** Red Hat 9.0: Restart Ethernet Card

```
[root@localhost init.d]# network restart

Shutting down interface eth0:           [OK]
Shutting down loopback interface:       [OK]
Setting network parameters:             [OK]
Bringing up loopback interface:         [OK]
Bringing up interface eth0:             [OK]
```



## Verifying Settings

Enter `ifconfig` in a terminal screen to check your TCP/IP properties.

**Figure 47** Red Hat 9.0: Checking TCP/IP Properties

```
[root@localhost]# ifconfig
eth0      Link encap:Ethernet  HWaddr 00:50:BA:72:5B:44
          inet addr:172.23.19.129  Bcast:172.23.19.255  Mask:255.255.255.0
          UP BROADCAST RUNNING MULTICAST  MTU:1500  Metric:1
          RX packets:717 errors:0 dropped:0 overruns:0 frame:0
          TX packets:13 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:100
          RX bytes:730412 (713.2 Kb)  TX bytes:1570 (1.5 Kb)
          Interrupt:10 Base address:0x1000
[root@localhost]#
```



# Common Services

The commonly used services and port numbers are shown in the following table. Please refer to RFC 1700 for further information about port numbers. Next to the name of the service, two fields appear in brackets. The first field indicates the IP protocol type (TCP, UDP, or ICMP). The second field indicates the IP port number that defines the service. (Note that there may be more than one IP protocol type. For example, look at the DNS service. (UDP/TCP: 53) means UDP port 53 and TCP port 53.

**Table 30** Commonly Used Services

SERVICE	DESCRIPTION
AIM/New-ICQ(TCP:5190)	AOL's Internet Messenger service, used as a listening port by ICQ.
AUTH(TCP: 113)	Authentication protocol used by some servers.
BGP(TCP: 179)	Border Gateway Protocol.
BOOTP_CLIENT(UDP:68)	DHCP Client.
BOOTP_SERVER(UDP:67)	DHCP Server.
CU-SEEME(TCP/UDP: 7648, 24032)	A popular videoconferencing solution from White Pines Software.
DNS(UDP/TCP: 53)	Domain Name Server, a service that matches web names (e.g. <a href="http://www.zyxel.com">www.zyxel.com</a> ) to IP numbers.
FINGER(TCP: 79)	Finger is a UNIX or Internet related command that can be used to find out if a user is logged on.
FTP(TCP: 20, 21)	File Transfer Program, a program to enable fast transfer of files, including large files that may not be possible by e-mail.
H.323(TCP: 1720)	NetMeeting uses this protocol.
HTTP(TCP: 80)	Hyper Text Transfer Protocol - a client/server protocol for the world wide web.
HTTPS(TCP: 443)	HTTPS is a secured http session often used in e-commerce.
ICQ(UDP: 4000)	This is a popular Internet chat program.
IKE(UDP: 500)	The Internet Key Exchange algorithm is used for key distribution and management.
IPSEC_TUNNEL(AH: 0)	The IPSEC AH (Authentication Header) tunneling protocol uses this service.
IPSEC_TUNNEL(ESP: 0)	The IPSEC ESP (Encapsulation Security Protocol) tunneling protocol uses this service.
IRC(TCP/UDP: 6667)	This is another popular Internet chat program.

**Table 30** Commonly Used Services

SERVICE	DESCRIPTION
MSN Messenger(TCP: 1863)	Microsoft Networks' messenger service uses this protocol.
MULTICAST(IGMP:0)	Internet Group Multicast Protocol is used when sending packets to a specific group of hosts.
NEW-ICQ(TCP:5190)	An Internet chat program.
NEWS(TCP: 144)	A protocol for news groups.
NFS(UDP: 2049)	Network File System - NFS is a client/server distributed file service that provides transparent file sharing for network environments.
NNTP(TCP: 119)	Network News Transport Protocol is the delivery mechanism for the USENET newsgroup service.
PING(ICMP:0)	Packet Internet Groper is a protocol that sends out ICMP echo requests to test whether or not a remote host is reachable.
POP3(TCP: 110)	Post Office Protocol version 3 lets a client computer get e-mail from a POP3 server through a temporary connection (TCP/IP or other).
PPTP(TCP: 1723)	Point-to-Point Tunneling Protocol enables secure transfer of data over public networks. This is the control channel.
PPTP_TUNNEL(GRE: 0)	Point-to-Point Tunneling Protocol enables secure transfer of data over public networks. This is the data channel.
RCMD(TCP: 512)	Remote Command Service.
REAL_AUDIO(TCP: 7070)	A streaming audio service that enables real time sound over the web.
REXEC(TCP: 514)	Remote Execution Daemon.
RLOGIN(TCP: 513)	Remote Login.
RTELNET(TCP: 107)	Remote Telnet.
RTSP(TCP/UDP: 554)	The Real Time Streaming (media control) Protocol (RTSP) is a remote control for multimedia on the Internet.
SFTP(TCP: 115)	Simple File Transfer Protocol.
SMTP(TCP: 25)	Simple Mail Transfer Protocol is the message-exchange standard for the Internet. SMTP enables you to move messages from one e-mail server to another.
SNMP(TCP/UDP: 161)	Simple Network Management Program.
SNMP-TRAPS(TCP/UDP: 162)	Traps for use with the SNMP (RFC: 1215).
SQL-NET(TCP: 1521)	Structured Query Language is an interface to access data on many different types of database systems, including mainframes, midrange systems, UNIX systems and network servers.
SSH(TCP/UDP: 22)	Secure Shell Remote Login Program.
STRM WORKS(UDP: 1558)	Stream Works Protocol.
SYSLOG(UDP: 514)	Syslog allows you to send system logs to a UNIX server.
TACACS(UDP: 49)	Login Host Protocol used for (Terminal Access Controller Access Control System).

**Table 30** Commonly Used Services

SERVICE	DESCRIPTION
TELNET(TCP:23)	Telnet is the login and terminal emulation protocol common on the Internet and in UNIX environments. It operates over TCP/IP networks. Its primary function is to allow users to log into remote host systems.
TFTP(UDP:69)	Trivial File Transfer Protocol is an Internet file transfer protocol similar to FTP, but uses the UDP (User Datagram Protocol) rather than TCP (Transmission Control Protocol).
VDOLIVE(TCP:7000)	Another videoconferencing solution.



# Legal Information

## Copyright

Copyright ZyXEL Communications Corporation.

The contents of this publication may not be reproduced in any part or as a whole, transcribed, stored in a retrieval system, translated into any language, or transmitted in any form or by any means, electronic, mechanical, magnetic, optical, chemical, photocopying, manual, or otherwise, without the prior written permission of ZyXEL Communications Corporation.

Published by ZyXEL Communications Corporation. All rights reserved.

## Disclaimer

ZyXEL does not assume any liability arising out of the application or use of any products, or software described herein. Neither does it convey any license under its patent rights nor the patent rights of others. ZyXEL further reserves the right to make changes in any products described herein without notice. This publication is subject to change without notice.

## Trademarks

ZyNOS (ZyXEL Network Operating System) is a registered trademark of ZyXEL Communications, Inc. Other trademarks mentioned in this publication are used for identification purposes only and may be properties of their respective owners.

## Certifications

### Federal Communications Commission (FCC) Interference Statement

The device complies with Part 15 of FCC rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference.

- This device must accept any interference received, including interference that may cause undesired operations.

This device has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this device does cause harmful interference to radio/television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- 1 Reorient or relocate the receiving antenna.
- 2 Increase the separation between the equipment and the receiver.
- 3 Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- 4 Consult the dealer or an experienced radio/TV technician for help.



### **FCC Radiation Exposure Statement**

- This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
- IEEE 802.11b or 802.11g operation of this product in the U.S.A. is firmware-limited to channels 1 through 11.
- To comply with FCC RF exposure compliance requirements, a separation distance of at least 20 cm must be maintained between the antenna of this device and all persons.

## **注意 ！**

依據 低功率電波輻射性電機管理辦法

第十二條 經型式認證合格之低功率射頻電機，非經許可，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。

第十四條 低功率射頻電機之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。

前項合法通信，指依電信規定作業之無線電信。低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。



## Notices

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device has been designed for the WLAN 2.4 GHz network throughout the EC region and Switzerland, with restrictions in France.

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

## Viewing Certifications

- 1 Go to <http://www.zyxel.com>.
- 2 Select your product on the ZyXEL home page to go to that product's page.
- 3 Select the certification you wish to view from this page.

## ZyXEL Limited Warranty

ZyXEL warrants to the original end user (purchaser) that this product is free from any defects in materials or workmanship for a period of up to two years from the date of purchase. During the warranty period, and upon proof of purchase, should the product have indications of failure due to faulty workmanship and/or materials, ZyXEL will, at its discretion, repair or replace the defective products or components without charge for either parts or labor, and to whatever extent it shall deem necessary to restore the product or components to proper operating condition. Any replacement will consist of a new or re-manufactured functionally equivalent product of equal or higher value, and will be solely at the discretion of ZyXEL. This warranty shall not apply if the product has been modified, misused, tampered with, damaged by an act of God, or subjected to abnormal working conditions.

### Note

Repair or replacement, as provided under this warranty, is the exclusive remedy of the purchaser. This warranty is in lieu of all other warranties, express or implied, including any implied warranty of merchantability or fitness for a particular use or purpose. ZyXEL shall in no event be held liable for indirect or consequential damages of any kind to the purchaser.

To obtain the services of this warranty, contact ZyXEL's Service Center for your Return Material Authorization number (RMA). Products must be returned Postage Prepaid. It is recommended that the unit be insured when shipped. Any returned products without proof of purchase or those with an out-dated warranty will be repaired or replaced (at the discretion of ZyXEL) and the customer will be billed for parts and labor. All repaired or replaced products will be shipped by ZyXEL to the corresponding return address, Postage Paid. This warranty gives you specific legal rights, and you may also have other rights that vary from country to country.

### **Registration**

Register your product online to receive e-mail notices of firmware upgrades and information at [www.zyxel.com](http://www.zyxel.com) for global products, or at [www.us.zyxel.com](http://www.us.zyxel.com) for North American products.

# Customer Support

In the event of problems that cannot be solved by using this manual, you should contact your vendor. If you cannot contact your vendor, then contact a ZyXEL office for the region in which you bought the device. Regional offices are listed below (see also [http://www.zyxel.com/web/contact\\_us.php](http://www.zyxel.com/web/contact_us.php)). Please have the following information ready when you contact an office.

## Required Information

- Product model and serial number.
- Warranty Information.
- Date that you received your device.
- Brief description of the problem and the steps you took to solve it.

“+” is the (prefix) number you dial to make an international telephone call.

## Corporate Headquarters (Worldwide)

- Support E-mail: [support@zyxel.com.tw](mailto:support@zyxel.com.tw)
- Sales E-mail: [sales@zyxel.com.tw](mailto:sales@zyxel.com.tw)
- Telephone: +886-3-578-3942
- Fax: +886-3-578-2439
- Web: [www.zyxel.com](http://www.zyxel.com)
- Regular Mail: ZyXEL Communications Corp., 6 Innovation Road II, Science Park, Hsinchu 300, Taiwan

## China - ZyXEL Communications (Beijing) Corp.

- Support E-mail: [cso.zycn@zyxel.cn](mailto:cso.zycn@zyxel.cn)
- Sales E-mail: [sales@zyxel.cn](mailto:sales@zyxel.cn)
- Telephone: +86-010-82800646
- Fax: +86-010-82800587
- Address: 902, Unit B, Horizon Building, No.6, Zhichun Str, Haidian District, Beijing
- Web: <http://www.zyxel.cn>

## China - ZyXEL Communications (Shanghai) Corp.

- Support E-mail: [cso.zycn@zyxel.cn](mailto:cso.zycn@zyxel.cn)
- Sales E-mail: [sales@zyxel.cn](mailto:sales@zyxel.cn)
- Telephone: +86-021-61199055
- Fax: +86-021-52069033

- Address: 1005F, ShengGao International Tower, No.137 XianXia Rd., Shanghai
- Web: <http://www.zyxel.cn>

### **Costa Rica**

- Support E-mail: [soporte@zyxel.co.cr](mailto:soporte@zyxel.co.cr)
- Sales E-mail: [sales@zyxel.co.cr](mailto:sales@zyxel.co.cr)
- Telephone: +506-2017878
- Fax: +506-2015098
- Web: [www.zyxel.co.cr](http://www.zyxel.co.cr)
- Regular Mail: ZyXEL Costa Rica, Plaza Roble Escazú, Etapa El Patio, Tercer Piso, San José, Costa Rica

### **Czech Republic**

- E-mail: [info@cz.zyxel.com](mailto:info@cz.zyxel.com)
- Telephone: +420-241-091-350
- Fax: +420-241-091-359
- Web: [www.zyxel.cz](http://www.zyxel.cz)
- Regular Mail: ZyXEL Communications, Czech s.r.o., Modranská 621, 143 01 Praha 4 - Modrany, Česká Republika

### **Denmark**

- Support E-mail: [support@zyxel.dk](mailto:support@zyxel.dk)
- Sales E-mail: [sales@zyxel.dk](mailto:sales@zyxel.dk)
- Telephone: +45-39-55-07-00
- Fax: +45-39-55-07-07
- Web: [www.zyxel.dk](http://www.zyxel.dk)
- Regular Mail: ZyXEL Communications A/S, Columbusvej, 2860 Soeborg, Denmark

### **Finland**

- Support E-mail: [support@zyxel.fi](mailto:support@zyxel.fi)
- Sales E-mail: [sales@zyxel.fi](mailto:sales@zyxel.fi)
- Telephone: +358-9-4780-8411
- Fax: +358-9-4780-8448
- Web: [www.zyxel.fi](http://www.zyxel.fi)
- Regular Mail: ZyXEL Communications Oy, Malminkaari 10, 00700 Helsinki, Finland

### **France**

- E-mail: [info@zyxel.fr](mailto:info@zyxel.fr)
- Telephone: +33-4-72-52-97-97
- Fax: +33-4-72-52-19-20
- Web: [www.zyxel.fr](http://www.zyxel.fr)
- Regular Mail: ZyXEL France, 1 rue des Vergers, Bat. 1 / C, 69760 Limonest, France

**Germany**

- Support E-mail: [support@zyxel.de](mailto:support@zyxel.de)
- Sales E-mail: [sales@zyxel.de](mailto:sales@zyxel.de)
- Telephone: +49-2405-6909-69
- Fax: +49-2405-6909-99
- Web: [www.zyxel.de](http://www.zyxel.de)
- Regular Mail: ZyXEL Deutschland GmbH., Adenauerstr. 20/A2 D-52146, Wuerselen, Germany

**Hungary**

- Support E-mail: [support@zyxel.hu](mailto:support@zyxel.hu)
- Sales E-mail: [info@zyxel.hu](mailto:info@zyxel.hu)
- Telephone: +36-1-3361649
- Fax: +36-1-3259100
- Web: [www.zyxel.hu](http://www.zyxel.hu)
- Regular Mail: ZyXEL Hungary, 48, Zoldlomb Str., H-1025, Budapest, Hungary

**India**

- Support E-mail: [support@zyxel.in](mailto:support@zyxel.in)
- Sales E-mail: [sales@zyxel.in](mailto:sales@zyxel.in)
- Telephone: +91-11-30888144 to +91-11-30888153
- Fax: +91-11-30888149, +91-11-26810715
- Web: <http://www.zyxel.in>
- Regular Mail: India - ZyXEL Technology India Pvt Ltd., II-Floor, F2/9 Okhla Phase -1, New Delhi 110020, India

**Japan**

- Support E-mail: [support@zyxel.co.jp](mailto:support@zyxel.co.jp)
- Sales E-mail: [zyp@zyxel.co.jp](mailto:zyp@zyxel.co.jp)
- Telephone: +81-3-6847-3700
- Fax: +81-3-6847-3705
- Web: [www.zyxel.co.jp](http://www.zyxel.co.jp)
- Regular Mail: ZyXEL Japan, 3F, Office T&U, 1-10-10 Higashi-Gotanda, Shinagawa-ku, Tokyo 141-0022, Japan

**Kazakhstan**

- Support: <http://zyxel.kz/support>
- Sales E-mail: [sales@zyxel.kz](mailto:sales@zyxel.kz)
- Telephone: +7-3272-590-698
- Fax: +7-3272-590-689
- Web: [www.zyxel.kz](http://www.zyxel.kz)
- Regular Mail: ZyXEL Kazakhstan, 43 Dostyk Ave., Office 414, Dostyk Business Centre, 050010 Almaty, Republic of Kazakhstan

### **Malaysia**

- Support E-mail: [support@zyxel.com.my](mailto:support@zyxel.com.my)
- Sales E-mail: [sales@zyxel.com.my](mailto:sales@zyxel.com.my)
- Telephone: +603-8076-9933
- Fax: +603-8076-9833
- Web: <http://www.zyxel.com.my>
- Regular Mail: ZyXEL Malaysia Sdn Bhd., 1-02 & 1-03, Jalan Kenari 17F, Bandar Puchong Jaya, 47100 Puchong, Selangor Darul Ehsan, Malaysia

### **North America**

- Support E-mail: [support@zyxel.com](mailto:support@zyxel.com)
- Support Telephone: +1-800-978-7222
- Sales E-mail: [sales@zyxel.com](mailto:sales@zyxel.com)
- Sales Telephone: +1-714-632-0882
- Fax: +1-714-632-0858
- Web: [www.zyxel.com](http://www.zyxel.com)
- Regular Mail: ZyXEL Communications Inc., 1130 N. Miller St., Anaheim, CA 92806-2001, U.S.A.

### **Norway**

- Support E-mail: [support@zyxel.no](mailto:support@zyxel.no)
- Sales E-mail: [sales@zyxel.no](mailto:sales@zyxel.no)
- Telephone: +47-22-80-61-80
- Fax: +47-22-80-61-81
- Web: [www.zyxel.no](http://www.zyxel.no)
- Regular Mail: ZyXEL Communications A/S, Nils Hansens vei 13, 0667 Oslo, Norway

### **Poland**

- E-mail: [info@pl.zyxel.com](mailto:info@pl.zyxel.com)
- Telephone: +48-22-333 8250
- Fax: +48-22-333 8251
- Web: [www.pl.zyxel.com](http://www.pl.zyxel.com)
- Regular Mail: ZyXEL Communications, ul. Okrzei 1A, 03-715 Warszawa, Poland

### **Russia**

- Support: <http://zyxel.ru/support>
- Sales E-mail: [sales@zyxel.ru](mailto:sales@zyxel.ru)
- Telephone: +7-095-542-89-29
- Fax: +7-095-542-89-25
- Web: [www.zyxel.ru](http://www.zyxel.ru)
- Regular Mail: ZyXEL Russia, Ostrovityanova 37a Str., Moscow 117279, Russia

**Singapore**

- Support E-mail: support@zyxel.com.sg
- Sales E-mail: sales@zyxel.com.sg
- Telephone: +65-6899-6678
- Fax: +65-6899-8887
- Web: <http://www.zyxel.com.sg>
- Regular Mail: ZyXEL Singapore Pte Ltd., No. 2 International Business Park, The Strategy #03-28, Singapore 609930

**Spain**

- Support E-mail: support@zyxel.es
- Sales E-mail: sales@zyxel.es
- Telephone: +34-902-195-420
- Fax: +34-913-005-345
- Web: [www.zyxel.es](http://www.zyxel.es)
- Regular Mail: ZyXEL Communications, Arte, 21 5ª planta, 28033 Madrid, Spain

**Sweden**

- Support E-mail: support@zyxel.se
- Sales E-mail: sales@zyxel.se
- Telephone: +46-31-744-7700
- Fax: +46-31-744-7701
- Web: [www.zyxel.se](http://www.zyxel.se)
- Regular Mail: ZyXEL Communications A/S, Sjöporten 4, 41764 Göteborg, Sweden

**Taiwan**

- Support E-mail: support@zyxel.com.tw
- Sales E-mail: sales@zyxel.com.tw
- Telephone: +886-2-27399889
- Fax: +886-2-27353220
- Web: <http://www.zyxel.com.tw>
- Address: Room B, 21F, No.333, Sec. 2, Dunhua S. Rd., Da-an District, Taipei

**Thailand**

- Support E-mail: support@zyxel.co.th
- Sales E-mail: sales@zyxel.co.th
- Telephone: +662-831-5315
- Fax: +662-831-5395
- Web: <http://www.zyxel.co.th>
- Regular Mail: ZyXEL Thailand Co., Ltd., 1/1 Moo 2, Ratchaphruk Road, Bangrak-Noi, Muang, Nonthaburi 11000, Thailand.

### **Turkey**

- Support E-mail: [cso@zyxel.com.tr](mailto:cso@zyxel.com.tr)
- Telephone: +90 212 222 55 22
- Fax: +90-212-220-2526
- Web: <http://www.zyxel.com.tr>
- Address: Kaptanpasa Mahallesi Piyalepasa Bulvari Ortadogu Plaza N:14/13 K:6 Okmeydani/Sisli Istanbul/Turkey

### **Ukraine**

- Support E-mail: [support@ua.zyxel.com](mailto:support@ua.zyxel.com)
- Sales E-mail: [sales@ua.zyxel.com](mailto:sales@ua.zyxel.com)
- Telephone: +380-44-247-69-78
- Fax: +380-44-494-49-32
- Web: [www.ua.zyxel.com](http://www.ua.zyxel.com)
- Regular Mail: ZyXEL Ukraine, 13, Pimonenko Str., Kiev 04050, Ukraine

### **United Kingdom**

- Support E-mail: [support@zyxel.co.uk](mailto:support@zyxel.co.uk)
- Sales E-mail: [sales@zyxel.co.uk](mailto:sales@zyxel.co.uk)
- Telephone: +44-1344-303044, 0845 122 0301 (UK only)
- Fax: +44-1344-303034
- Web: [www.zyxel.co.uk](http://www.zyxel.co.uk)
- Regular Mail: ZyXEL Communications UK Ltd., 11 The Courtyard, Eastern Road, Bracknell, Berkshire RG12 2XB, United Kingdom (UK)



# Index

## A

access control in WLAN [61](#)  
Access Point (AP), see AP [51](#)  
Advanced Encryption Standard (AES) [58](#)  
AES (Advanced Encryption Standard) [58](#)  
AP (Access Point) [51](#)  
authentication in WLAN [53](#), [57](#)

## B

band plans [67](#)  
band scan [66](#)  
Baseline Privacy (BP) [30](#)  
boot state [29](#), [36](#)  
BP [36](#)  
BP (Baseline Privacy) [30](#)  
BPI (Baseline Privacy Interface) [36](#)  
BPI+ [36](#)

## C

Cable Home 1.1 [19](#)  
certifications [103](#)  
    notices [105](#)  
    viewing [105](#)  
channels [31](#)  
compliance [19](#)  
configuration file [30](#), [36](#)  
connection status [32](#)  
contact information [107](#)  
copyright [103](#)  
customer support [107](#)

## D

default configuration [24](#)  
default IP address [72](#)  
default login information [72](#)  
device defaults [72](#)  
device specifications [72](#)  
DHCP [71](#)  
DHCP (Dynamic Host Configuration Protocol) [43](#)  
DHCP client [44](#)  
DHCP server [44](#)  
diagnostics [64](#)  
dimensions [72](#)  
disclaimer [103](#)  
DOCSIS 2.0 [19](#)  
downstream channel [29](#), [31](#), [35](#), [72](#)  
Dynamic Host Configuration Protocol (DHCP) [43](#)

## E

encryption in WLAN [53](#), [58](#)  
encryption key [54](#)  
Ethernet ports [72](#)  
event log [37](#)  
    descriptions [38](#)  
    severity levels [37](#)

## F

factory defaults [64](#)  
FCC interference statement [103](#)  
features [71](#)  
firmware  
    features [71](#)  
firmware information [31](#)

**I**

IEEE 802.11b/g data rates [72](#)  
IEEE 802.1x [53](#)  
Internet access [19](#), [71](#)  
IP address [43](#)  
IP filtering [47](#)  
IP pool setup [43](#)  
IP Security (IPSec) [45](#)  
IPSec (IP Security) [45](#)

**J**

Java permissions [23](#)  
JavaScript [23](#)

**L**

LED descriptions [20](#)  
logging in [23](#), [26](#)

**M**

MAC address filter [48](#), [52](#), [61](#)  
maintenance [63](#)  
management idle timeout period [30](#)  
model types [19](#)  
multicast [46](#)

**N**

NAT [71](#)  
    port forwarding [50](#)  
NAT (Network Address Translation) [45](#)  
navigating the web configurator [25](#), [30](#)

**P**

password [24](#), [26](#), [63](#)  
    changing [26](#)  
    default [72](#)  
physical specifications [72](#)  
ping test [65](#), [66](#)  
Point-to-Point Tunneling Protocol (PPTP) [45](#)  
pop-up windows [23](#)  
port filtering [49](#)  
port forwarding [50](#), [71](#)  
power adaptor specifications [74](#)  
PPTP (Point-to-Point Tunneling Protocol) [45](#)  
product registration [106](#)

**R**

radio frequency [55](#)  
RADIUS [53](#), [56](#)  
registration  
    product [106](#)  
related documentation [3](#)  
reset button [24](#)  
resetting [24](#), [64](#)

**S**

safety warnings [6](#)  
security [30](#), [36](#), [72](#)  
    IP filtering [47](#)  
    MAC filtering [48](#)  
    password [63](#)  
    port filtering [49](#)  
    WLAN [52](#)  
Service Set IDentity (SSID) [51](#)  
software information [31](#)  
SSID [52](#)  
SSID (Service Set IDentity) [51](#)  
standards compliance [19](#)  
startup procedure [33](#)  
    detail [35](#)  
status [31](#)

- connection [32](#)
- event log [37](#)
- status indicators, LEDs [20](#)
- syntax conventions [4](#)
- system requirements [72](#)
- system status [31](#)

## T

- Temporal Key Integrity Protocol (TKIP) [58](#)
- TKIP (Temporal Key Integrity Protocol) [58](#)
- trademarks [103](#)
- types of models [19](#)

## U

- upstream channel [31](#)
- USB port [19](#), [72](#)
- user name [24](#)
  - default [72](#)

## V

- Virtual Private Network (VPN) [45](#)
- VPN (Virtual Private Network) [45](#)
- VPN passthrough [45](#)

## W

- warranty [105](#)
  - note [105](#)
- web configurator [25](#)
  - advanced features [45](#)
  - DHCP [44](#)
  - diagnostics [64](#)
  - home [25](#)
  - login [23](#)
  - maintenance [63](#)
  - navigation [25](#)
  - requirements [23](#)

- status [31](#)
- WLAN [54](#)
- WEP [53](#), [55](#)
- WEP (Wired Equivalent Privacy) [57](#)
- Wi-Fi Protected Access (WPA) [57](#)
- Wireless Local Area Network (WLAN) [51](#)
- wireless model [19](#)
- WLAN
  - access control [61](#)
  - authentication [53](#), [57](#)
  - basic setup [54](#)
  - encryption [53](#), [58](#)
  - encryption key [54](#)
  - guidelines [51](#)
  - MAC address [52](#)
  - network name [52](#)
  - security [52](#), [53](#), [55](#)
  - web configurator [54](#)
- WLAN (Wireless Local Area Network) [51](#)
- WLAN overview [51](#)
- WPA [53](#)
- WPA (Wi-Fi Protected Access) [57](#)
- WPA -Pre-Shared Key [60](#)
- WPA-PSK [53](#), [60](#)

